



Online Tower UPS



Manual

DN-170130, DN-170131, DN-170132

Table of Contents

1. Important Safety Warning	3
1-1 Transportation	3
1-2 Preparation	3
1-3 Installation	3
1-4 Operation.....	4
1-5 Maintenance, service and faults	4
2. Installation and setup.....	5
2-1 Unpack checking	5
2-2 Real panel view.....	6
2-3 Setup the UPS	6
2-4 UPS startup and turn off	7
3. Operations	12
3-1 Button Operation	12
3-2 LCD display.....	13
3-3 UPS setting.....	14
3-4 Alarm or Fault reference code.....	18
4. Troubleshooting	19
5. Storage and Maintenance	22
6. Options	22
7. Specification	25

1. Important Safety Warning

Important safety instructions – Save these instructions

Please comply with all warnings and operating instructions in this manual strictly. Save this manual properly and read carefully the following instructions before installing the unit. Do not operate this unit before reading through all safety information and operating instructions carefully

There exist dangerous voltage and high temperature inside the UPS. During the installation, operation and maintenance, please abide by the local safety instructions and relative laws, otherwise it will result in personnel injury or equipment damage. Safety instructions in this manual act as a supplementary for the local safety instructions. The liability will not be assumed if it is caused by disobeying safety instructions.

1-1 Transportation

- Please transport the UPS system only in the original package to protect against shock and impact.

1-2 Preparation

- Condensation may occur if the UPS system is moved directly from cold to warm environment. The UPS system must be dry before being installed. Please allow at least two hours for the UPS system to acclimate the environment.
- Do not install the UPS system near water or in moist environments.
- Do not install the UPS system where it would be exposed to direct sunlight or near heater.
- Do not block ventilation holes in the UPS housing.

1-3 Installation

- Do not connect appliances or devices which would overload the UPS system (e.g. laser printers) to the UPS output sockets.
- Place cables in such a way that no one can step on or trip over them.
- Do not connect domestic appliances such as hair dryers to UPS output sockets.
- The UPS cannot be operated by any individuals with no previous experience.
- Connect the UPS system only to an earthed shockproof outlet which must be easily accessible and close to the UPS system.

- Please use only VDE-tested, CE-marked mains cable (e.g. the mains cable of your computer) to connect the UPS system to the building wiring outlet (shockproof outlet).
- Please use only VDE-tested, CE-marked power cables to connect the loads to the UPS system.
- When installing the equipment, it should ensure that the sum of the leakage current of the UPS and the connected devices does not exceed 3.5mA.
- Before installing the UPS, pay attention to the installation environment and do not install it in places with high temperature, humidity, and dust etc.

1-4 Operation

- Do not disconnect the mains cable on the UPS system or the building wiring outlet (shockproof socket outlet) during operations since this would cancel the protective earthing of the UPS system and of all connected loads.
- The UPS system features its own, internal current source (batteries). The UPS output sockets, or output terminals block may be electrically live even if the UPS system is not connected to the building wiring outlet.
- To fully disconnect the UPS system, first press the OFF/Enter button to disconnect the mains.
- Prevent no fluids or other foreign objects from inside of the UPS system.

1-5 Maintenance, service and faults

- The UPS system operates with hazardous voltages. Repairs may be carried out only by qualified maintenance personnel.
- **Caution** - Risk of electric shock. Even after the unit is disconnected from the mains (building wiring outlet), components inside the UPS system are still connected to the battery and electrically live and dangerous.
- Before carrying out any kind of service and/or maintenance, disconnect the batteries and verify that no current is present, and no hazardous voltage exists in the terminals of high capability capacitors such as BUS-capacitors.
- Only people are adequately familiar with batteries and with the required precautionary measures that may replace batteries and supervise operations. Unauthorized people must be kept well away from the batteries.
- **Caution** - Risk of electric shock. The battery circuit is not isolated from the input voltage. Hazardous voltages may occur between the battery terminals and the ground. Before touching, please verify that no voltage is present!

- Batteries may cause electric shock and have a high short-circuit current. Please take the precautionary measures specified below and any other measures necessary when working with batteries:
 - Remove wristwatches, rings and other metal objects
 - Use only tools with insulated grips and handles.
- When changing batteries, install the same number and same type of batteries.
- Do not attempt to dispose of batteries by burning them. This could cause battery explosion.
- Do not open or destroy batteries. Escaping electrolyte can cause injury to the skin and eyes. It may be toxic.
- Please replace the fuse only with the same type and amperage in order to avoid fire hazards.
- Do not dismantle the UPS system.

2. Installation and setup

NOTE: Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. Please keep the original package in a safe place for future use.


2-1 Unpack checking

- Don't lean the UPS when moving it out from the packaging.
- Check the appearance to see if the UPS is damaged or not during the transportation, do not switch on the UPS if any damage found. Please contact the dealer right away.
- Check the accessories according to the packing list and contact the dealer in case of missing parts.

It includes:

- UPS quick installation guide
- USB cable
- Power cord (Input or output)
- RS232 cable

2-2 Real panel view



1KVA Rear Panel View

2KVA Rear Panel View

3KVA Rear Panel View

1	Intelligent slot	6	Input breaker
2	Battery socket	7	RS232
3	Output socket	8	USB
4	Net surge protection	9	EPO
5	Input socket	10	Fan

2-3 Setup the UPS

Step 1: UPS input connection


Plug the UPS into a two-pole, three-wire, grounded receptacle only. Avoid using extension cords. The power cord is supplied in the UPS package.

Step 2: UPS output connection

Simply connect devices to the outlets.

Step 3: Communication connection

Communication port:

USB port	RS-232 port	Intelligent slot
		

To allow for unattended UPS shutdown/start-up and status monitoring, connect the communication cable one end to the USB/RS-232 port and the other to the communication port of your PC. With the monitoring software installed, you can schedule UPS shutdown/start-up and monitor UPS status through PC.

The UPS is equipped with intelligent slot perfect for either optional SNMP or Relay card. When installing either SNMP or Relay card in UPS, it will provide advanced communication and monitoring options.

NOTE: USB port and RS-232 port can't work at the same time.

Step 4: Turn on the UPS

Press the ON button on the front panel for three seconds to power on the UPS.

Note: The battery charges fully during the first five hours of normal operation. Do not expect full battery run capability during this initial charge period.

Note: Suggest charging at least 12 hours before 1st use.

Step 5: Install software

UPS Monitoring Software  https://ftp.assmann.com/pub/DN-/DN-170130_4016032507925/DN-170130_addon_en_UPS%20Software_20251023.zip	Download the software installation files & user manual (above or on https://de.assmann.shop/). Execute KPower to start installation. Search "KPower" in your PC and open the software.
---	---

2-4UPS startup and turn off

Startup operation

1. Turn on the UPS in line mode

NOTE: Verify that the total equipment ratings do not exceed the UPS capacity to prevent an overload alarm.

- When the UPS is connected to mains power, it will automatically enter standby mode. In this mode, there will be no output, and all indicator lights will remain off. However, the UPS will still begin charging the battery, even though the lights are not on. No action is required to start battery charging.
- If you need the UPS to provide power to the connected load (i.e., switch to

inverter output mode), press and hold the “ON” button for more than 3 seconds to turn on the UPS and activate the inverter output.

- Once started, UPS will perform a self-test function. LED will light and go out circularly and orderly. When the self-test finishes, it will come to line mode, the corresponding LED lights, the UPS is working in line mode.

2. Turn on the UPS by DC without mains power

- When mains power is disconnected, press and hold the ON key for more than half a second to start UPS.
- The operation of the UPS in the process of starting is almost the same as that when mains power is in. After finishing the self-test, the corresponding LED lights and the UPS is working in battery mode.

Turn off operation

1. Turn off the UPS in line mode

- Press and hold the OFF key for more than half a second to turn off the UPS and inverter.
- After the UPS shutdown, the LEDs go out and there is no output. If output is needed, you can set bypass (BPS) “ON” on the LCD setting menu.


2. Turn off the UPS by DC without mains power

- Press and hold the OFF key for more than three seconds to turn off the UPS.
- When turning off the UPS, it will do self-testing first. The LEDs light and go out circularly and orderly until there is no display on the cover.

Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the UPS. It includes four indicators, four function keys and an LCD display, indicating the operating status and input/output power information.

LCD control panel introduction




LED Indicator

Indicator	Description
 Red	Alarm: On, the UPS has an active alarm or fault.
 Yellow	Bypass: The UPS is in Bypass mode. On, the UPS is operating normally on bypass during High Efficiency operation.
 Yellow	Battery: On, the UPS is in Battery mode.
 Green	Inverter: On, the UPS is operating normally.
NOTE: When power is on or startup, these indicators will turn on and off sequentially. NOTE: On different operation modes, these indicators will indicate differently.	


Function Keys

Function Key	Description
ENTER/ON	To turn on the ups or confirm the selection in setting mode or enter setting mode
ESC/OFF	To turn off the ups or exit setting mode without save.
UP	To go to previous selection
Down	To go to next selection

LCD Display Icons



Icon	Function description
Input Source Information	
AC	Indicates the AC input.
INPUTBATT 888 kW VA % Hz °C	Indicates input voltage, input frequency, battery voltage and Temperature.
Configuration Program and Fault Information	
88 ⚙️	Indicates the setting programs.
88 ⚠️ 88 ERROR	Indicates the warning and fault codes.
	Warning: 88 ⚠️ flashing with warning code.
	Fault: 88 ERROR lighting with fault code
	Indicates the setting programs.

Output Information					
OUTPUTBATTLOAD 888 kW VA % Hz		Indicate output voltage, output frequency, load percent, load in VA, load in Watt			
Battery Information					
 CHARGING		Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode.			
In AC mode, it will present battery charging status.					
Status	Battery capacity		LCD Display		
Floating mode	0-24%		4 bars will flash in turns		
	25-49%		Bottom bar will be on and the other three bars will flash in turns		
	50-74%		Bottom two bars will be on and the other two bars will flash in turns		
	75-100%		Bottom three bars will be on and the top bars will flash		
Load Information					
OVER LOAD		Indicates overload.			
SHORT		Indicates output short circuit fault. When the external device or load device at the UPS output is short-circuited, the indicator light will be on.			
		Indicates the load level by 0-24%, 25-49%, 50-74% and 75-100%.			
		0%~24%	25%~49%	50%~74%	75%~100%
					
Mode Operation Information					
		Indicates unit connects to the mains.			
BYPASS BPS		Indicates load is supplied by utility power.			
ECO		Indicates load is supplied by utility power.			
CF		Converts frequency when the load requires a different frequency than the input. Bypass mode is disabled in this mode.			

	Indicates the utility charger circuit is working.
	Indicates the DC/AC inverter circuit is working.
Mute Operation	
	Indicates unit alarm is disabled.

3. Operations

3-1 Button Operation

Button	Function
ON /ENTER Button	Turn on the UPS: Press and hold ON button for at least 3 seconds to turn on the UPS. Confirm current settings: When the UPS enters the setting mode, it is necessary to press this button to confirm the settings value. Out of bypass mode: When the UPS enters to bypass mode, press and hold this button. It will switch to normal mode. Switch to UPS self-test mode: Press and hold this button for 2 seconds to enter UPS self-testing while in AC mode.
OFF/ESC Button	Turn off the UPS: Press and hold this button at least 3 seconds to turn off the UPS in battery mode. UPS will be in standby mode under normal power or transfer to bypass mode if the Bypass enables setting by pressing this button. Exit setting mode: Press this button to exit setting mode when in UPS setting mode but save nothing.
UP Button	Up key: Press this button to display previous selection in UPS setting mode.
DOWN Button	Down key: Press this button to display next selection in UPS setting mode. To confirm selection and exit setting mode: Press this button to confirm selection and exit setting mode when LCD display the last selection in UPS setting mode.
UP + DOWN Button	Setting mode: Press and hold this button for 5 seconds to enter UPS setting mode.

3-2 LCD display

There are 8 interfaces available in the LCD display.

Item	Interface Description	Content Displayed
01	Input voltage& Output voltage	
02	Input frequency& Output frequency	
03	Battery voltage& Battery capacity	
04	Load	

05	Environmental Temperature	
06	UPS model	
07	Firmware Version	
08	Alarm Code (Warning Message) All alarm codes are present when abnormal behavior(s) occur(s)	

3-3 UPS setting

The UPS has setting functions. These user settings can be done under any kind of UPS working mode. The setting will take effect under certain conditions. Below table describes how to set the UPS.

The setting function is controlled by 4 buttons (Up, Down, ON/Enter, OFF/ESC):

Up ▲+Down ▼ for Five seconds---goes into the setting page,

ON/Enter ---- confirm the setting options

Up ▲ & Down ▼ ---value adjustment or for choosing different pages.

After the UPS turn ON, press buttons “▲&▼” for 5 seconds and then goes into the setting interface page.

Note: Press “Down” button to confirm selection and exit setting mode when LCD display the last selection in UPS setting mode.

Item	Settings	Content display
01	Mode setting Press Enter button to change the setting (ECO or NOR or CF or GEN). Note 1 Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.	
02	Output voltage setting Press Enter button to change the setting (200, 208, 220, 230, 240). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.	
03	Frequency setting Press Enter button to change the setting (50 or 60Hz). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.	
04	Battery capacity setting Press Enter button to change the setting (Battery capacity range is 1-200Ah). Note 2 Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.	

05	Battery EOD voltage setting (Segment 1) Press Enter button to change the setting (1.75/1.84/1.92). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.	
06	Battery EOD voltage setting (Segment 2) Press Enter button to change the setting (1.60/1.70/1.75/1.80). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.	
07	Bypass voltage upper limit setting Press Enter button to change the setting (The bypass voltage upper limit range is 230-264Vac). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.	
08	Bypass voltage lower limit setting Press Enter button to change the setting (The bypass voltage lower limit range is 176-220Vac). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.	

09	Mute setting Press Enter button to change the setting (ON or OFF). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to save and exit the setup.	
10	BYPASS enable/disable setting Press Enter button to change the setting (ON or OFF). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to save and exit the setup.	

Note 1

Nor = Normal mode, AC mode, mains mode.

CF = Converts frequency when the load requires a different frequency than the input. Bypass mode is disabled in this mode.

GEN: Genset mode, provide a wider input range to handle generator voltage and frequency fluctuations

Note 2

UPS supports up to 4pcs optional external battery modules (EBPs). To ensure display the battery backup time more accurately, it is necessary to set the correct battery capacity. According to the number of built-in batteries and external battery boxes of UPS, the total capacity of batteries connected to UPS is calculated, and the battery capacity of UPS is set through LCD screen (connected battery capacity =(AH number of single battery * battery capacity setting number of groups);

The following table shows the battery pack number and ah setting value of ups and its supporting battery box.

All UPS and EBP cabinets	Number of battery strings	UPS LCD Battery capacity setting
UPS only (internal batteries)	1 (default)	9AH (default)
UPS + 1 EBP	3	27AH
UPS + 2 EBPs	5	45AH
UPS + 3 EBPs	7	63AH

UPS + 4 EBPs	9	81AH
Note: The UPS contains one battery string; each EBP contains two battery strings.		

3-4 Alarm or Fault reference code

Event log	UPS Alarm Warning	Buzzer	LED
1	Rectifier Fault	Beep continuously	Fault LED lit
2	Inverter fault (Including Inverter bridge is shorted)	Beep continuously	Fault LED lit
9	Fan fault	Beep continuously	Fault LED lit
12	Self-test fault	Beep continuously	Fault LED lit
13	Battery Charger fault	Beep continuously	Fault LED lit
15	DC Bus over voltage	Beep continuously	Fault LED lit
16	DC Bus below voltage	Beep continuously	Fault LED lit
17	DC bus unbalance	Beep continuously	Fault LED lit
18	Soft start failed	Beep continuously	Fault LED lit
19	Environment temperature Over Temperature	Twice per second	Fault LED blinking
20	Inverter model Over Temperature	Twice per second	Fault LED blinking
26	Battery over voltage	Twice per second	Fault LED blinking
27	Mains Input reverse	Once per second	Fault LED blinking
28	Bypass Input reverse	Once per second	Fault LED blinking
29	Output Short-circuit	Beep continuously	Fault LED lit
30	Input current limit	Once per second	Fault LED blinking
31	Bypass over current	Once per second	BPS LED blinking
32	Overload	Once per second	INV or BPS LED blinking
33	No battery	Once per second	Battery LED blinking
34	Battery under voltage	Once per second	Battery LED blinking
35	Battery low pre-warning	Once per 2 seconds	Battery LED blinking
36	Overload time out	Once per 2 seconds	Fault LED blinking
37	DC component over limit.	Once per 2 seconds	INV LED blinking
39	Mains volt. Abnormal	Once per 2 seconds	BPS LED blinking

40	Mains freq. abnormal	Once per 2 seconds	BPS LED blinking
41	Bypass Not Available	None	BPS LED blinking
42	Bypass out of tracking range	None	BPS LED blinking
45	EPO Enable	Beep continuously	Fault LED lit


4. Troubleshooting

If the UPS system does not operate correctly, please solve the problem by using the table below and the Trouble Shooting Chart.

Symptom	Possible cause	Remedy
No indication and alarm even though the mains are normal.	The AC input power is not connected well.	Check if input power cord firmly connected to the mains.
	The AC input is connected to the UPS output.	Plug AC input power cord to AC input correctly.
Alarm code is shown as "33" and battery led blinking.	The external or internal battery is incorrectly connected.	Check if all batteries are connected well.
Alarm code is shown as "26" and battery led blinking.	Battery voltage is too high, or the charger is faulty.	Contact your dealer.
Alarm code is shown as "34" and battery led blinking	Battery voltage is too low, or the charger is faulty.	Contact your dealer.
Alarm code is shown as "32" and INV or BYPASS led blinking.	UPS is overload	Remove excess loads from UPS output.
Alarm code is shown as "27&28" and FAULT led light.	Mains Input reverse& Bypass Input reverse	Check input L/N wiring Reverse connection
Alarm code is shown as "29" and FAULT led light.	The UPS shut down automatically because short circuit occurs on the UPS output.	Check output wiring and see if connected devices are in short circuit status.
Alarm code is shown as "9" and FAULT led light.	Fan fault.	Contact your dealer.

Alarm code is shown as "01,02,15,16,17,18"	A UPS internal fault has occurred.	Contact your dealer.
Battery backup time is shorter than nominal value	Batteries are not fully charged	Charge the batteries for at least 5 hours and then check capacity. If the problem still persists, consult your dealer.
	Batteries defect	Contact your dealer to replace the battery.

Trouble Shooting Chart



5. Storage and Maintenance

Operation

The UPS system contains no user-serviceable parts. If the battery service life (3~5 years at 25°C ambient temperature) has been exceeded, the batteries must be replaced. In this case, please contact your dealer.

 Dh	 Dh	Be sure to deliver the spent battery to a recycling facility or ship it to your dealer in the replacement battery packing material.
---	---	---

Storage

Before storage, charge UPS for 5 hours. Store the UPS covered and upright in a cool, dry location. During storage, recharge the battery in accordance with the following table:

Storage Temperature	Recharge Frequency	Charging Duration
-25°C - 40°C	Every 3 months	1-2 hours
40°C - 45°C	Every 2 months	hours

6. Options

SNMP card: internal SNMP (Options)

- Loosen the 2 torque screws (on each side of the card).
- Carefully insert the SNMP card and lock the screws


Digitus DN-170100-1 is a built-in network SNMP card independently. It supports SNMPv1/v2 and v3 protocols, features e-mail alarm, historical events and historical data storage. This is a tool to remotely monitor and manage any UPS system.



Relay card (Options)

Mini dry contact card is used for providing an interface for UPS peripheral monitoring. The contact signals can reflect UPS running status. The card is connected to peripheral monitoring devices via terminal board to facilitate the effective monitoring of the real-time status of UPS and timely feedback the status to monitor when abnormal situation occurs (such as UPS failure, mains interruption, UPS bypass and act.). It is installed in the intelligent slot of the UPS.

The relay card includes 6 output ports and one input port. Please refer to the following table for detail.



Pins definition of connecting terminal on the board

Terminal No.	Terminal function	Terminal No.	Terminal function
1	Common source	9	Bypass enable NO
2	UPS on NC	10	Bypass enable NC
3	AC fail NO	11	UPS fail NO
4	AC fail NC	12	UPS fail NC
5	Batt low NO	CN4-1	Remote shutdown
6	Batt low NC	CN4-2	GND
7	UPS alarm NO		
8	UPS alarm NC		

Relay card electrical parameter

	max	Type
Relay card contact	(Max Switched Voltage)	AC:120V
	AC:120V	DC:5~12V
	DC:24V	
	(Max Switched Current)	AC:1A
	AC:1A	DC:1A
	DC:1A	

Emergency Power-off (EPO)

EPO is used to shut down UPS from a distance. This feature can be used for shutting down the load and UPS by thermal relay, for instance in the event of room over temperature. When EPO is activated, the UPS shuts down the output and all its power converters immediately. The UPS remains on to alarm the fault.




EPO Connections

NOTE: Depending on user configuration, the pins must be shorted or opened to keep the UPS running. To restart the UPS, reconnect (re-open) the EPO connector pins and turn on the UPS manually. Maximum resistance in the shorted loop is 10 ohms.

Always test the EPO function before applying your critical load to avoid accidental load loss. **Leave the EPO connector installed onto the EPO port of the UPS even if the EPO function is not needed.**

Power Shedding

Power shedding are sets of receptacles that can be controlled by power management software or through the display, providing an orderly shutdown and startup of your equipment. For example, during a power outage, you can keep critical equipment running while you turn off other equipment. This feature allows you to save battery power. Each UPS has two load segments:



Segment 1: The power shedding battery voltage of this segment can be set by LCD.

(Refer to Battery EOD voltage setting (Segment 1))

Segment 2: The power shedding battery end of discharge (EOD).

7. Specification

MODEL		DN-170130	DN-170131	DN-170132
PHASE		Single phase with ground		
Capacity (VA/Watts)		1000VA /1000W	2000VA / 2000W	3000VA / 3000W
INPUT				
Nominal voltage		200/208/220/230/240VAC		
Operating voltage range (Ambient Temp. <40°C)	Low line transfer	176Vac±5% @100%-50% load; 110Vac±5% @50%-0% load;		
	Low line comeback	186Vac±5% @100%-50% load; 120Vac±5% @50%-0% load;		
	High line transfer	264Vac±5% @100%-50% load; 300Vac±5% @50%-0% load;		
	High line comeback	254Vac±5% @100%-50% load; 290Vac±5% @50%-0% load;		
Operating frequency range**		40-70Hz		
Power factor		0.99@100% load (Nominal Input Voltage)		
Bypass voltage range		Bypass high voltage point: 230-264: setting the high voltage point in LCD from 230Vac to 264Vac. (Default: 264Vac) Bypass low voltage point: 176-220: setting the low voltage point in LCD from 176Vac to 220Vac. (Default: 176Vac)		
Generator input		Support		
OUTPUT				
Output voltage*		200/208/220/230/240Vac		
Power factor		1.0		
Voltage regulation		±1%		
Frequency	Line Mode (synchronized range)	46-54Hz or 56-64Hz		
	Bat. Mode	(50/60±0.1) Hz		
Crest factor		3:1		

Harmonic distortion (THDv)		≤3% THD with linear load ≤5% THD with non-linear load		
Waveform		Pure Sinewave		
Transfer time	AC mode <->Batt. mode	Zero		
	Inverter <-> bypass	4ms (Typical)		
Efficiency (up to)		89% (AC mode)	90% (AC mode)	91% (AC mode)
BATTERY				
Battery Type		12V9AH		
Numbers		2	4	6
Backup time		Long run unit depends on the capacity of external batteries		
Typical recharge time (standard model)		4 hours recover to 90% capacity (typical)		
Charging voltage		27.4 ±1%	54.7±1%	82.1 ±1%
Charge current(A)		2		
SYSTEM FEATURES				
Overload	Line Mode	105%~125%: UPS transfers to bypass after 1minute when the utility is normal. 125%~130%: UPS transfers to bypass after 30 seconds when the utility is normal. >130%: UPS transfers to bypass immediately when the utility is normal.		
	Batt. Mode	105%~125%: UPS shuts down after 1 minute. 125%~130%: UPS shuts down after 10 seconds. >130%: UPS shuts down immediately.		
Short Circuit		Hold Whole System		
Overheat		Line Mode: Switch to Bypass; Backup Mode: Shut down UPS immediately		
Low battery voltage		Alarm and switch off		
EPO (optional)		Shut down UPS immediately		
Audible & Visual alarms		Line Failure, Battery Low, Overload, System Fault		
Communication interface		USB (or RS232), SNMP card (optional), Relay card (optional)		
ENVIRONMENTAL				
Operating temperature		0℃~40℃		
Storage temperature		-25℃~55℃		
Humidity range		20-90 % RH @ 0- 40℃ (non-condensing)		
Altitude		< 1500m		
Noise level		Less than 55 dBA at 1 Meter		
PHYSICAL				
Dimension W×D×H (mm)		144x 293x 209	191x 460x 337	
Net Weight (kg)		9.1	19.5	24.5

* Derate to 80% of capacity when the output voltage is adjusted to 200/208VAC

** Derate to 75% of capacity when the Input voltage frequency out of range (50/60±4Hz)

*** Product specifications are subject to change without further notice.

This is a Class C2 product. In home environment, this product may cause radio interference. In this case, the user may be required to take appropriate measures.

Hereby Assmann Electronic GmbH, declares that the Declaration of Conformity is part of the shipping content. If the Declaration of Conformity is missing, you can request it by post under the below mentioned manufacturer address.

info@assmann.com
Assmann Electronic GmbH
Auf dem Schüffel 3
58513 Lüdenscheid
Germany

