# Printer Compatibility List

Update:2026.07.08

| Printer Manufacture | Printer Model | Print Server Model | | | |
|---|---|---|---|---|---|
| | | DN-13006-1 | DN-13003-1<br>DN-13003-2 | DN-13014-3 | DN-13001-1 |
| | | 2U1P | 1U | 1U | 1P |
| HP | Business InkJet 1000 | OK | OK | OK | |
| HP | Color Laserjet 150a | OK | OK | OK | |
| HP | Color Laserjet 1500L | OK | OK | OK | |
| HP | Color Laserjet 1600 | OK | OK | OK | |
| HP | Color Laserjet 2500 | OK | OK | OK | OK |
| HP | Color LaserJet 2550 | OK | OK | OK | OK |
| HP | Color LaserJet 2550L/LN | OK | OK | OK | |
| HP | Color LaserJet 2600 | OK | OK | OK | |
| HP | Color LaserJet 2605 | OK | OK | OK | OK |
| HP | Color LaserJet 2700n | OK | OK | OK | |
| HP | Color LaserJet 2840 | OK | OK | OK | |
| HP | Color LaserJet 3700 | OK | OK | OK | OK |
| HP | Color LaserJet 4000 | OK | | | OK |
| HP | Color LaserJet 4100 | OK | | | OK |
| HP | Color LaserJet 4500 | OK | | | OK |
| HP | Color Laserjet 4650 | OK | OK | OK | OK |
| HP | Color LaserJet 8550 | OK | | | OK |
| HP | Color Laserjet CP1215 | OK | OK | OK | |
| HP | Color Laserjet CP1525nw | OK | OK | OK | |
| HP | Color Laserjet CM1312 MFP | OK | OK | OK | |
| HP | Color Laserjet CM1015 MFP | OK | OK | OK | |
| HP | Color Laserjet MFP M281fdw | OK | OK | OK | |
| HP | Designjet 100 | OK | OK | OK | OK |
| HP | Designjet 600 | OK | | | OK |
| HP | Designjet 650C | OK | | | OK |
| HP | Designjet 700 | OK | | | OK |
| HP | Designjet 750C+ | OK | | | OK |
| HP | Deskjet 1010 | OK | OK | OK | |
| HP | Deskjet 1110 | OK | OK | OK | |
| HP | DeskJet 1120C | OK | | | OK |
| HP | Deskjet 1125C | OK | OK | OK | OK |
| HP | Deskjet 1180C | OK | OK | OK | OK |
| HP | DeskJet 1280 | OK | OK | OK | OK |
| HP | Deskjet 1510 | OK | OK | OK | |
| HP | Deskjet 2000 J210 | OK | OK | OK | |
| HP | Deskjet 2020hc | OK | OK | OK | |
| HP | Deskjet 2050 | OK | OK | OK | |
| HP | Deskjet 2130 | OK | OK | OK | |
| HP | Deskjet 2510 | OK | OK | OK | |
| HP | Deskjet 2511 | OK | OK | OK | |
| HP | Deskjet 2512 | OK | OK | OK | |
| HP | Deskjet 2515 | OK | OK | OK | |
| HP | Deskjet 2516 | OK | OK | OK | |
| HP | Deskjet IA 2520hc | OK | OK | OK | |
| HP | Deskjet 2540 | OK | OK | OK | |
| HP | Deskjet 2621 | OK | OK | OK | |
| HP | Deskjet 3000 | OK | OK | OK | |
| HP | Deskjet 3070A | OK | OK | OK | |
| HP | Deskjet 3050 | OK | OK | OK | |
| HP | Deskjet 3325 | OK | OK | OK | |
| HP | DeskJet 3420 | OK | OK | OK | |
| HP | Deskjet 3520 | OK | OK | OK | |
| HP | Deskjet 3535 | OK | OK | OK | |
| HP | Deskjet 3630 | OK | OK | OK | |
| HP | Deskjet 3631 | OK | OK | OK | |
| HP | Deskjet 3632 | OK | OK | OK | |
| HP | Deskjet 3633 | OK | OK | OK | |
| HP | Deskjet 3634 | OK | OK | OK | |
| HP | Deskjet 3635 | OK | OK | OK | |
| HP | Deskjet 3636 | OK | OK | OK | |
| HP | Deskjet 3637 | OK | OK | OK | |
| HP | Deskjet 3638 | OK | OK | OK | |
| HP | Deskjet 3650 | OK | OK | OK | |
| HP | Deskjet 3743 | OK | OK | OK | |
| HP | Deskjet 3748 | OK | OK | OK | |
| HP | Deskjet 3820 | OK | OK | OK | OK |
| HP | DeskJet 3920 | OK | OK | OK | |
| HP | DeskJet 3940 | OK | OK | OK | |
| HP | DeskJet 400/420 | OK | | | OK |
| HP | Deskjet 450C | OK | OK | OK | OK |
| HP | Deskjet 5440 | OK | OK | OK | |

| | | | | | |
|---|---|---|---|---|---|
| **HP** | DeskJet 5500 | OK | | | OK |
| **HP** | Deskjet 5550 | OK | OK | OK | OK |
| **HP** | Deskjet 5560 | OK | OK | OK | |
| **HP** | Deskjet 5652 | OK | OK | OK | OK |
| **HP** | Deskjet 670C | OK | | | OK |
| **HP** | Deskjet 680C | OK | | | OK |
| **HP** | Deskjet 720C | OK | | | OK |
| **HP** | Deskjet 810C | OK | OK | OK | OK |
| **HP** | Deskjet 830C | OK | OK | OK | OK |
| **HP** | Deskjet 845C | OK | OK | OK | |
| **HP** | DeskJet 9300 | OK | OK | OK | OK |
| **HP** | Deskjet 948c | OK | OK | OK | OK |
| **HP** | Deskjet 9600 | OK | OK | OK | OK |
| **HP** | Deskjet 9650 | OK | OK | OK | OK |
| **HP** | Deskjet 970c XI | OK | OK | OK | OK |
| **HP** | Deskjet 9800 | OK | OK | OK | OK |
| **HP** | Deskjet D1560 | OK | OK | OK | |
| **HP** | Deskjet D2560 | OK | OK | OK | |
| **HP** | Deskjet D5560 | OK | OK | OK | |
| **HP** | DeskJet F370 | OK | OK | OK | |
| **HP** | DeskJet F380 | OK | OK | OK | |
| **HP** | DeskJet F4185 | OK | OK | OK | |
| **HP** | DeskJet F4280 | OK | OK | OK | |
| **HP** | Deskjet F4480 | OK | OK | OK | |
| **HP** | Deskjet IA 2529 | OK | OK | OK | |
| **HP** | Deskjet IA 3635 | OK | OK | OK | |
| **HP** | Deskjet IA 3636 | OK | OK | OK | |
| **HP** | Deskjet IA 3638 | OK | OK | OK | |
| **HP** | Deskjet IA Ultra 4729 | OK | OK | OK | |
| **HP** | Ink Tenk 110 | OK | OK | OK | |
| **HP** | Ink Tenk 115 | OK | OK | OK | |
| **HP** | Laserjet Pro M401n | OK | OK | OK | |
| **HP** | Laserjet M1005 MFP | OK | OK | OK | |
| **HP** | LaserJet 1022 | OK | OK | OK | |
| **HP** | LaserJet 1022N | OK | OK | OK | |
| **HP** | Laserjet 1100 | OK | | | OK |
| **HP** | LaserJet 1160 | OK | OK | OK | OK |
| **HP** | LaserJet 1200 | OK | OK | OK | OK |
| **HP** | LaserJet 1220 | OK | OK | OK | OK |
| **HP** | Laserjet 1300 | OK | OK | OK | OK |
| **HP** | Laserjet 1320 | OK | OK | OK | OK |
| **HP** | Laserjet M1522n MFP | OK | OK | OK | |
| **HP** | LaserJet 2100 | OK | | | OK |
| **HP** | Laserjet 2200d | OK | OK | OK | OK |
| **HP** | Laserjet 2300 | OK | OK | OK | OK |
| **HP** | LaserJet 2410 | OK | OK | OK | OK |
| **HP** | LaserJet 2420 | OK | OK | OK | OK |
| **HP** | LaserJet 2550 | OK | OK | OK | OK |
| **HP** | LaserJet 3015 | OK | OK | OK | OK |
| **HP** | LaserJet 3050 | OK | OK | OK | |
| **HP** | LaserJet 3055 | OK | OK | OK | |
| **HP** | Laserjet 3200 | OK | OK | OK | OK |
| **HP** | Laserjet 3330 | OK | OK | OK | OK |
| **HP** | LaserJet 3330mfp | OK | OK | OK | OK |
| **HP** | LaserJet 3380 | OK | OK | OK | |
| **HP** | Laserjet 4000 | OK | | | OK |
| **HP** | LaserJet 4050 | OK | | | OK |
| **HP** | Laserjet 4100 /4100n | OK | | | OK |
| **HP** | LaserJet 4250 | OK | OK | OK | OK |
| **HP** | Laserjet 4300n | OK | | | OK |
| **HP** | Laserjet 4300tn/dtn | OK | | | OK |
| **HP** | Laserjet Color 4500 | OK | | | OK |
| **HP** | Laserjet 4650 | OK | OK | OK | OK |
| **HP** | Laserjet 5100fn/tn | OK | | | OK |
| **HP** | Laserjet 5100le/se | OK | | | OK |
| **HP** | Laserjet 6P / 6L | OK | | | OK |
| **HP** | Laserjet 700 M712dn | | OK | OK | |
| **HP** | Laserjet 8100 | OK | | | OK |
| **HP** | Laserjet M1005 | OK | OK | OK | |
| **HP** | Laserjet M1005 MFP | OK | OK | OK | |
| **HP** | Laserjet M111W | OK | OK | OK | |
| **HP** | Laserjet M141W | OK | OK | OK | |
| **HP** | Laserjet M1120 MFP | OK | OK | OK | |
| **HP** | LaserJet M1319F MFP | OK | OK | OK | |
| **HP** | Laserjet MFP 139FNW | OK | OK | OK | |
| **HP** | Laserjet MFP M72630 | OK | OK | OK | |
| **HP** | Laserjet MFP M42625dn | OK | OK | OK | |

| | | | | | |
|---|---|---|---|---|---|
| **HP** | LaserJet P2015 | OK | OK | OK | |
| **HP** | LaserJet P2035 | OK | OK | OK | OK |
| **HP** | Laserjet Pro 3003dw | OK | OK | OK | |
| **HP** | Laserjet Pro 4003dn | OK | OK | OK | must disable "Bi-directional support |
| **HP** | Laserjet Pro M127fn | OK | OK | OK | |
| **HP** | Laserjet Pro M130a | OK | OK | OK | |
| **HP** | Laserjet Pro M15W | OK | OK | OK | |
| **HP** | Laserjet Pro M1536dnf | OK | OK | OK | |
| **HP** | Laserjet Pro M26a | OK | OK | OK | |
| **HP** | Laserjet Pro M26nw | OK | OK | OK | |
| **HP** | Laserjet Pro M28 | OK | OK | OK | |
| **HP** | Laserjet Pro M425dn MFP | OK | OK | OK | |
| **HP** | Laserjet Pro M428f | OK | OK | OK | |
| **HP** | Laserjet Pro M521dn | OK | OK | OK | |
| **HP** | Laserjet Pro MFP 3103fdw | OK | OK | OK | |
| **HP** | Laserjet Pro MFP 4103fdw | OK | OK | OK | |
| **HP** | Laserjet Pro MFP M236sdw | OK | OK | OK | |
| **HP** | Laserjet Enterprise M406dn | OK | OK | OK | |
| **HP** | Laserjet Enterprise M507dn | OK | OK | OK | |
| **HP** | Laserjet Enterprise M611dn | OK | OK | OK | |
| **HP** | Laserjet Enterprise MFP M430f | OK | OK | OK | |
| **HP** | Officejet J3608 | OK | OK | OK | |
| **HP** | Officejet 2620 | OK | OK | OK | |
| **HP** | OfficeJet 4255 | OK | OK | OK | |
| **HP** | Officejet 4500 | OK | OK | OK | |
| **HP** | Officejet 4610 | OK | OK | OK | |
| **HP** | Officejet 4620 | OK | OK | OK | |
| **HP** | Officejet 4630 | OK | OK | OK | |
| **HP** | OfficeJet 5610 | OK | OK | OK | |
| **HP** | Officejet J5780 | OK | OK | OK | |
| **HP** | OfficeJet 6210 | OK | OK | OK | |
| **HP** | OfficeJet 6310 | OK | OK | OK | |
| **HP** | Officejet 6000 | OK | OK | OK | |
| **HP** | Officejet 6100 eP | OK | OK | OK | |
| **HP** | Officejet 6500 | OK | OK | OK | |
| **HP** | Officejet 6600 | OK | OK | OK | |
| **HP** | Officejet 6700 | OK | OK | OK | |
| **HP** | Officejet 7000 | OK | | | |
| **HP** | Officejet 7500A | OK | OK | OK | |
| **HP** | OfficeJet 7210 | OK | OK | OK | |
| **HP** | OfficeJet J4580 | OK | OK | OK | |
| **HP** | Officejet J4660 | OK | OK | OK | |
| **HP** | Officejet J6480 | OK | OK | OK | |
| **HP** | Officejet K7100 | OK | OK | OK | |
| **HP** | OfficeJet K850 | OK | OK | OK | OK |
| **HP** | OfficeJet Pro K5300 | OK | OK | OK | |
| **HP** | OfficeJet Pro K550 | OK | OK | OK | |
| **HP** | OfficeJet Pro K8600 | OK | OK | OK | |
| **HP** | Officejet Pro L7380 | OK | OK | OK | |
| **HP** | Officejet Pro L7590 | OK | OK | OK | |
| **HP** | Officejet Pro 6230 | OK | OK | OK | |
| **HP** | Officejet Pro 6500A Plus | OK | OK | OK | |
| **HP** | Officejet Pro 6830 | OK | OK | OK | |
| **HP** | Officejet Pro 7000 | OK | OK | OK | |
| **HP** | Officejet Pro 8000 | OK | OK | OK | |
| **HP** | Officejet Pro 8100 | OK | OK | OK | |
| **HP** | Officejet Pro 8500A Plus | OK | OK | OK | |
| **HP** | Officejet Pro 8500W | OK | OK | OK | |
| **HP** | Officejet Pro 8600 | OK | OK | OK | |
| **HP** | Officejet Pro 8600 Plus | OK | OK | OK | |
| **HP** | Officejet Pro 8610 | OK | OK | OK | |
| **HP** | Officejet Pro 8620 | OK | OK | OK | |
| **HP** | Photosmart 2610 | OK | OK | OK | |
| **HP** | Photosmart 3110 | OK | OK | OK | |
| **HP** | Photosmart 5510 | OK | OK | OK | |
| **HP** | Photosmart 5520 | OK | OK | OK | |
| **HP** | Photosmart 6510 | OK | OK | OK | |
| **HP** | Photosmart 6520 | OK | OK | OK | |
| **HP** | Photosmart 7150 | OK | OK | OK | |
| **HP** | Photosmart 7200 | OK | OK | OK | |
| **HP** | Photosmart 7510 | OK | OK | OK | |
| **HP** | Photosmart 7550 | OK | OK | OK | |
| **HP** | Photosmart 7660 | OK | OK | OK | |
| **HP** | Photosmart 7830 | OK | OK | OK | |
| **HP** | Photosmart 7900 | OK | OK | OK | |
| **HP** | Photosmart 8200 | OK | OK | OK | |
| **HP** | Photosmart Plus B209a | OK | OK | OK | |

| | | | | | |
|---|---|---|---|---|---|
| **HP** | Photosmart Plus B210a | OK | OK | OK | |
| **HP** | Photosmart Plus C310a | OK | OK | OK | |
| **HP** | Photosmart A520 | OK | OK | OK | |
| **HP** | Photosmart B109a | OK | OK | OK | |
| **HP** | Photosmart B110a AIO | OK | OK | OK | |
| **HP** | Photosmart C309a | OK | OK | OK | |
| **HP** | Photosmart C410a | OK | OK | OK | |
| **HP** | Photosmart C3180 | OK | OK | OK | |
| **HP** | Photosmart C4180 | OK | OK | OK | |
| **HP** | Photosmart C4280 | OK | OK | OK | |
| **HP** | Photosmart C4385 | OK | OK | OK | |
| **HP** | Photosmart C4480 | OK | OK | OK | |
| **HP** | Photosmart C4580 | OK | OK | OK | |
| **HP** | Photosmart C5180 | OK | OK | OK | |
| **HP** | Photosmart C5280 | OK | OK | OK | |
| **HP** | Photosmart C5380 | OK | OK | OK | |
| **HP** | Photosmart C6180 | OK | OK | OK | |
| **HP** | Photosmart C6280 | OK | OK | OK | |
| **HP** | Photosmart C6380 | OK | OK | OK | |
| **HP** | Photosmart C7180 | OK | OK | OK | |
| **HP** | Photosmart C7280 | OK | OK | OK | |
| **HP** | Photosmart C8180 | OK | OK | OK | |
| **HP** | Photosmart D5160 | OK | OK | OK | |
| **HP** | Photosmart D5360 | OK | OK | OK | |
| **HP** | Photosmart D5460 | OK | OK | OK | |
| **HP** | Photosmart D7160 | OK | OK | OK | |
| **HP** | Photosmart D7260 | OK | OK | OK | |
| **HP** | Photosmart D7360 | OK | OK | OK | |
| **HP** | Photosmart Premium C309g | OK | OK | OK | |
| **HP** | Photosmart Premium C310g | OK | OK | OK | |
| **HP** | PSC 1210 | OK | | | |
| **HP** | PSC 1315 | OK | OK | OK | |
| **HP** | PSC 1350 | OK | OK | OK | |
| **HP** | PSC 1410 | OK | OK | OK | |
| **HP** | PSC 1610 | OK | OK | OK | |
| **HP** | PSC 2210 | OK | OK | OK | |
| **HP** | PSC 2310 | OK | OK | OK | |
| **HP** | Smart Tank 215 | OK | OK | OK | |
| **HP** | Smart Tank 500 | OK | OK | OK | |
| **HP** | Smart Tank 510 | OK | OK | OK | |
| **HP** | Smart Tank 515 | OK | OK | OK | |
| **HP** | Smart Tank 580 | OK | OK | OK | |
| **HP** | Smart Tank 610 | OK | OK | OK | |
| **HP** | Smart Tank 725 | OK | OK | OK | |
| **HP** | Smart Tank 755 | OK | OK | OK | |
| **HP** | Smart Tank 795 | OK | OK | OK | |
| **EPSON** | Aculaser C500 | OK | OK | OK | |
| **EPSON** | Aculaser C1100SE | OK | OK | OK | OK |
| **EPSON** | Aculaser C1600 | OK | OK | OK | |
| **EPSON** | Aculaser C1700 | OK | OK | OK | |
| **EPSON** | Aculaser C1750N | OK | OK | OK | |
| **EPSON** | Aculaser C1750W | OK | OK | OK | |
| **EPSON** | Aculaser C1900 | OK | OK | OK | OK |
| **EPSON** | Aculaser C2900 | OK | OK | OK | |
| **EPSON** | Aculaser C300DN | OK | OK | OK | |
| **EPSON** | Aculaser C3800 | OK | OK | OK | |
| **EPSON** | Aculaser C3900N | OK | OK | OK | |
| **EPSON** | Aculaser C9100 | OK | OK | OK | |
| **EPSON** | Aculaser CX16NF | OK | OK | OK | |
| **EPSON** | Aculaser CX17NF | OK | OK | OK | |
| **EPSON** | Aculaser M1400 | OK | OK | OK | |
| **EPSON** | Aculaser M2010DN | OK | OK | OK | |
| **EPSON** | Aculaser M2010D | OK | OK | OK | OK |
| **EPSON** | Aculaser M2310D | OK | OK | OK | OK |
| **EPSON** | Aculaser M2310DN | OK | OK | OK | |
| **EPSON** | Aculaser M2410D | OK | OK | OK | OK |
| **EPSON** | Aculaser M2410DN | OK | OK | OK | |
| **EPSON** | Aculaser MX14 | OK | OK | OK | |
| **EPSON** | Aculaser MX14NF | OK | OK | OK | |
| **EPSON** | AL-M200DN | OK | OK | OK | |
| **EPSON** | AL-M220DN | OK | OK | OK | |
| **EPSON** | AL-M310DN | OK | OK | OK | |
| **EPSON** | AL-M4000 | OK | OK | OK | |
| **EPSON** | AL-M7000 | OK | OK | OK | |
| **EPSON** | AL-M8000 | OK | OK | OK | OK |
| **EPSON** | AL-M8200DN | OK | OK | OK | |
| **EPSON** | AL-MX200DWF | OK | OK | OK | |

| | | | | | |
|---|---|---|---|---|---|
| **EPSON** | B-508DN | OK | OK | OK | |
| **EPSON** | B-518DN | OK | OK | OK | |
| **EPSON** | C750 | OK | OK | OK | OK |
| **EPSON** | CC-500L | OK | OK | OK | |
| **EPSON** | CL-760 | OK | OK | OK | |
| **EPSON** | E-300L | OK | OK | OK | |
| **EPSON** | E-520 | OK | OK | OK | |
| **EPSON** | E-720 | OK | OK | OK | |
| **EPSON** | EC-01 | OK | OK | OK | |
| **EPSON** | EPL 5700 | OK | | | OK |
| **EPSON** | EPL 5700 | OK | | | OK |
| **EPSON** | EPL 5800 | OK | OK | OK | OK |
| **EPSON** | EPL 5800 | OK | OK | OK | OK |
| **EPSON** | EPL 5900 | OK | OK | OK | OK |
| **EPSON** | EPL 6100 | OK | OK | OK | OK |
| **EPSON** | EPL 6200 | OK | OK | OK | OK |
| **EPSON** | EPL N2120 | OK | | | OK |
| **EPSON** | K100 | OK | OK | OK | |
| **EPSON** | L110 | OK | OK | OK | |
| **EPSON** | L120 | OK | OK | OK | |
| **EPSON** | L121 | OK | OK | OK | |
| **EPSON** | L200 | OK | OK | OK | |
| **EPSON** | L210 | OK | OK | OK | |
| **EPSON** | L220 | OK | OK | OK | |
| **EPSON** | L300 | OK | OK | OK | |
| **EPSON** | L310 | OK | OK | OK | |
| **EPSON** | L350 | OK | OK | OK | |
| **EPSON** | L355 | OK | OK | OK | |
| **EPSON** | L360 | OK | OK | OK | |
| **EPSON** | L365 | OK | OK | OK | |
| **EPSON** | L380 | OK | OK | OK | |
| **EPSON** | L385 | OK | OK | OK | |
| **EPSON** | L455 | OK | OK | OK | |
| **EPSON** | L485 | OK | OK | OK | |
| **EPSON** | L550 | OK | OK | OK | |
| **EPSON** | L555 | OK | OK | OK | |
| **EPSON** | L565 | OK | OK | OK | |
| **EPSON** | L605 | OK | OK | OK | |
| **EPSON** | L565 | OK | OK | OK | |
| **EPSON** | L655 | OK | OK | OK | |
| **EPSON** | L800 | OK | OK | OK | |
| **EPSON** | L805 | OK | OK | OK | |
| **EPSON** | L1110 | OK | OK | OK | |
| **EPSON** | L1210 | OK | OK | OK | |
| **EPSON** | L1300 | OK | OK | OK | |
| **EPSON** | L1455 | OK | OK | OK | |
| **EPSON** | L1800 | OK | OK | OK | |
| **EPSON** | L3110 | OK | OK | OK | |
| **EPSON** | L3116 | OK | OK | OK | |
| **EPSON** | L3150 | OK | OK | OK | |
| **EPSON** | L3156 | OK | OK | OK | |
| **EPSON** | L3210 | OK | OK | OK | |
| **EPSON** | L3216 | OK | OK | OK | |
| **EPSON** | L3250 | OK | OK | OK | |
| **EPSON** | L3256 | OK | OK | OK | |
| **EPSON** | L3260 | OK | OK | OK | |
| **EPSON** | L3550 | OK | OK | OK | |
| **EPSON** | L3556 | OK | OK | OK | |
| **EPSON** | L3560 | OK | OK | OK | |
| **EPSON** | L4150 | OK | OK | OK | |
| **EPSON** | L4160 | OK | OK | OK | |
| **EPSON** | L4260 | OK | OK | OK | |
| **EPSON** | L5190 | OK | OK | OK | |
| **EPSON** | L5196 | OK | OK | OK | |
| **EPSON** | L5290 | OK | OK | OK | |
| **EPSON** | L5590 | OK | OK | OK | |
| **EPSON** | L6170 | OK | OK | OK | |
| **EPSON** | L6190 | OK | OK | OK | |
| **EPSON** | L6290 | OK | OK | OK | |
| **EPSON** | L6490 | OK | OK | OK | |
| **EPSON** | L6580 | OK | OK | OK | |
| **EPSON** | L14150 | OK | OK | OK | |
| **EPSON** | L15160 | OK | OK | OK | |
| **EPSON** | L18050 | OK | OK | OK | |
| **EPSON** | LP2500 | OK | OK | OK | |
| **EPSON** | LP-7700 | OK | OK | OK | |
| **EPSON** | LP-8700 | OK | OK | OK | |

| | | | | | |
|---|---|---|---|---|---|
| **EPSON** | LP-8800C | OK | OK | OK | |
| **EPSON** | LP8900 | OK | OK | OK | |
| **EPSON** | LP-9500C | OK | OK | OK | |
| **EPSON** | LQ 100 | OK | | | OK |
| **EPSON** | LQ 1000C | OK | | | OK |
| **EPSON** | LQ 1170+ | OK | | | OK |
| **EPSON** | LQ 1170C | OK | | | OK |
| **EPSON** | LQ 1170C+ | OK | | | OK |
| **EPSON** | LQ 2070C | OK | | | OK |
| **EPSON** | LQ 2080C | OK | | | OK |
| **EPSON** | LQ 2090 | OK | | | OK |
| **EPSON** | LQ 2090C | OK | OK | OK | OK |
| **EPSON** | LQ-2090CII | OK | OK | OK | OK |
| **EPSON** | LQ-2090CIIN | OK | OK | OK | OK |
| **EPSON** | LQ 2170C | OK | | | OK |
| **EPSON** | LQ 2180C | OK | | | OK |
| **EPSON** | LQ 2190C | OK | OK | OK | OK |
| **EPSON** | LQ 2550 | OK | | | OK |
| **EPSON** | LQ 300 | OK | | | OK |
| **EPSON** | LQ 300+ | OK | | | OK |
| **EPSON** | LQ 300+II | OK | OK | OK | OK |
| **EPSON** | LQ-310 | OK | OK | OK | OK |
| **EPSON** | LQ 3500C | OK | | | OK |
| **EPSON** | LQ 570C | OK | | | OK |
| **EPSON** | LQ-635C | OK | OK | OK | OK |
| **EPSON** | LQ 670 | OK | | | OK |
| **EPSON** | LQ 680 | OK | | | OK |
| **EPSON** | LQ 680C | OK | | | OK |
| **EPSON** | LQ-690C | OK | OK | OK | OK |
| **EPSON** | LQ-690CII | OK | OK | OK | OK |
| **EPSON** | M105 | OK | OK | OK | |
| **EPSON** | M200 | OK | OK | OK | |
| **EPSON** | M205 | OK | OK | OK | |
| **EPSON** | M1120 | OK | OK | OK | |
| **EPSON** | M1170 | OK | OK | OK | |
| **EPSON** | M2110 | OK | OK | OK | |
| **EPSON** | M2120 | OK | OK | OK | |
| **EPSON** | M2140 | OK | OK | OK | |
| **EPSON** | M2170 | OK | OK | OK | |
| **EPSON** | M3170 | OK | OK | OK | |
| **EPSON** | M15140 | OK | OK | OK | |
| **EPSON** | ME 320 | OK | OK | OK | |
| **EPSON** | ME 340 | OK | OK | OK | |
| **EPSON** | ME Office 82WD | OK | OK | OK | |
| **EPSON** | ME Office 900WD | OK | OK | OK | |
| **EPSON** | ME Office 940FW | OK | OK | OK | |
| **EPSON** | ME Office 960FWD | OK | OK | OK | |
| **EPSON** | MC-2000 | OK | OK | OK | |
| **EPSON** | PictureMate PM250 | OK | OK | OK | |
| **EPSON** | PLQ-20C | OK | OK | OK | |
| **EPSON** | PLQ-20CM | OK | OK | OK | |
| **EPSON** | PM-860PT | OK | OK | OK | |
| **EPSON** | PM-890C | OK | OK | OK | |
| **EPSON** | PM-920C | OK | OK | OK | |
| **EPSON** | PM-930C | OK | OK | OK | |
| **EPSON** | PM-950C | OK | OK | OK | |
| **EPSON** | PM-970C | OK | OK | OK | |
| **EPSON** | PM-980C | OK | OK | OK | |
| **EPSON** | PM-A550 | OK | OK | OK | |
| **EPSON** | PM-A620 | OK | OK | OK | |
| **EPSON** | PM-A650 | OK | OK | OK | |
| **EPSON** | PM-A720 | OK | OK | OK | |
| **EPSON** | PM-A820 | OK | OK | OK | |
| **EPSON** | PM-A840 | OK | OK | OK | |
| **EPSON** | PM-A850 | OK | OK | OK | |
| **EPSON** | PM-A890 | OK | OK | OK | |
| **EPSON** | PM-A900 | OK | OK | OK | |
| **EPSON** | PM-A920 | OK | OK | OK | |
| **EPSON** | PM-A940 | OK | OK | OK | |
| **EPSON** | PM-A950 | OK | OK | OK | |
| **EPSON** | PM-A970 | OK | OK | OK | |
| **EPSON** | PM-2200C | OK | OK | OK | |
| **EPSON** | PM-3500C | OK | OK | OK | |
| **EPSON** | PM-3700C | OK | OK | OK | |
| **EPSON** | PM-4000PX | OK | OK | OK | |
| **EPSON** | PM-D800 | OK | OK | OK | |
| **EPSON** | PM-D870 | OK | OK | OK | |

| | | | | | |
|---|---|---|---|---|---|
| **EPSON** | PM-D1000 | OK | OK | OK | |
| **EPSON** | PM-FA700 | OK | OK | OK | |
| **EPSON** | PM-G800 | OK | OK | OK | |
| **EPSON** | PM-G820 | OK | OK | OK | |
| **EPSON** | PM-G850 | OK | OK | OK | |
| **EPSON** | PM-G860 | OK | OK | OK | |
| **EPSON** | PM-G4500 | OK | OK | OK | |
| **EPSON** | PM-T960 | OK | OK | OK | |
| **EPSON** | PM-T990 | OK | OK | OK | |
| **EPSON** | PX-5000 | OK | OK | OK | |
| **EPSON** | PX-A640 | OK | OK | OK | |
| **EPSON** | PX-A740 | OK | OK | OK | |
| **EPSON** | PX-G5300 | OK | OK | OK | |
| **EPSON** | PX-G5100 | OK | OK | OK | |
| **EPSON** | PX-G930 | OK | OK | OK | |
| **EPSON** | PX-G5000 | OK | OK | OK | |
| **EPSON** | PX-V780 | OK | OK | OK | |
| **EPSON** | RX 510 | OK | OK | OK | |
| **EPSON** | RX 530 | OK | OK | OK | |
| **EPSON** | RX 590 | OK | OK | OK | |
| **EPSON** | RX 630 | OK | OK | OK | |
| **EPSON** | RX 690 | OK | OK | OK | |
| **EPSON** | Stylus C20 | OK | OK | OK | |
| **EPSON** | Stylus C40 | OK | OK | OK | |
| **EPSON** | Stylus C41UX/SX | OK | OK | OK | |
| **EPSON** | Stylus C43UX | OK | OK | OK | |
| **EPSON** | Stylus C45 | OK | OK | OK | |
| **EPSON** | Stylus C59 | OK | OK | OK | |
| **EPSON** | Stylus C60 | OK | OK | OK | OK |
| **EPSON** | Stylus C63 | OK | OK | OK | OK |
| **EPSON** | Stylus C67 | OK | OK | OK | OK |
| **EPSON** | Stylus C79 | OK | OK | OK | |
| **EPSON** | Stylus C83 | OK | | | OK |
| **EPSON** | Stylus C90 | OK | OK | OK | |
| **EPSON** | Stylus Color 1160 | OK | OK | OK | |
| **EPSON** | Stylus Color 1500 | OK | OK | OK | |
| **EPSON** | Stylus Color 1520 | OK | OK | OK | |
| **EPSON** | Stylus Color 400 | OK | | | OK |
| **EPSON** | Stylus Color 600 | OK | | | OK |
| **EPSON** | Stylus Color 670 | OK | OK | OK | OK |
| **EPSON** | Stylus Color 800 | OK | OK | OK | OK |
| **EPSON** | Stylus Color 810 | OK | OK | OK | OK |
| **EPSON** | Stylus Color 850 | OK | OK | OK | OK |
| **EPSON** | Stylus Color 900 | OK | OK | OK | |
| **EPSON** | Stylus CX-1500 | OK | OK | OK | |
| **EPSON** | Stylus CX-2900 | OK | OK | OK | |
| **EPSON** | Stylus CX-3500 | OK | OK | OK | |
| **EPSON** | Stylus CX-3700 | OK | OK | OK | |
| **EPSON** | Stylus CX-3900 | OK | OK | OK | |
| **EPSON** | Stylus CX-4100 | OK | OK | OK | |
| **EPSON** | Stylus CX-4700 | OK | OK | OK | |
| **EPSON** | Stylus CX-4900 | OK | OK | OK | |
| **EPSON** | Stylus CX-5300 | OK | OK | OK | |
| **EPSON** | Stylus CX-5500 | OK | OK | OK | |
| **EPSON** | Stylus CX-5505 | OK | OK | OK | |
| **EPSON** | Stylus CX-5900 | OK | OK | OK | |
| **EPSON** | Stylus CX-6900F | OK | OK | OK | |
| **EPSON** | Stylus CX-7300 | OK | OK | OK | |
| **EPSON** | Stylus CX-7800 | OK | OK | OK | |
| **EPSON** | Stylus CX-8300 | OK | OK | OK | |
| **EPSON** | Stylus CX-9300F | OK | OK | OK | |
| **EPSON** | Stylus Office T30 | OK | OK | OK | |
| **EPSON** | Stylus Office T40W | OK | OK | OK | |
| **EPSON** | Stylus Office TX300F | OK | OK | OK | |
| **EPSON** | Stylus Office TX320F | OK | OK | OK | |
| **EPSON** | Stylus Office TX510FN | OK | OK | OK | |
| **EPSON** | Stylus Office TX600FW | OK | OK | OK | |
| **EPSON** | Stylus Office TX610FW | OK | OK | OK | |
| **EPSON** | Stylus Office T1100 | OK | OK | OK | |
| **EPSON** | Stylus Photo 915 | OK | OK | OK | |
| **EPSON** | Stylus Photo 1270 | OK | OK | OK | OK |
| **EPSON** | Stylus Photo 1290 | OK | OK | OK | |
| **EPSON** | Stylus Photo 1390 | OK | OK | OK | |
| **EPSON** | Stylus Photo 2100 | OK | OK | OK | |
| **EPSON** | Stylus Photo 710 | OK | OK | OK | |
| **EPSON** | Stylus Photo 720 | OK | OK | OK | |
| **EPSON** | Stylus Photo 790 | OK | OK | OK | |

| | | | | | |
|---|---|---|---|---|---|
| **EPSON** | Stylus Photo 810 | OK | OK | OK | OK |
| **EPSON** | Stylus Photo 830U | OK | OK | OK | |
| **EPSON** | Stylus Photo 900 | OK | OK | OK | OK |
| **EPSON** | Stylus Photo 915 | OK | OK | OK | |
| **EPSON** | Stylus Photo EX2 | OK | OK | OK | OK |
| **EPSON** | Stylus Photo EX3 | OK | OK | OK | OK |
| **EPSON** | Stylus Photo R1800 | OK | OK | OK | OK |
| **EPSON** | Stylus Photo R210 | OK | OK | OK | |
| **EPSON** | Stylus Photo R230 | OK | OK | OK | |
| **EPSON** | Stylus Photo R250 | OK | OK | OK | |
| **EPSON** | Stylus Photo R270 | OK | OK | OK | |
| **EPSON** | Stylus Photo R310 | OK | OK | OK | |
| **EPSON** | Stylus Photo R350 | OK | OK | OK | |
| **EPSON** | Stylus Photo R2400 | OK | OK | OK | |
| **EPSON** | Stylus Photo R800 | OK | OK | OK | |
| **EPSON** | Stylus Photo RX430 | OK | OK | OK | |
| **EPSON** | Stylus Photo RX 510 | OK | OK | OK | |
| **EPSON** | Stylus Photo RX 530 | OK | OK | OK | |
| **EPSON** | Stylus Photo RX 590 | OK | OK | OK | |
| **EPSON** | Stylus Photo RX 630 | OK | OK | OK | |
| **EPSON** | Stylus Photo RX 650 | OK | OK | OK | |
| **EPSON** | Stylus Photo RX 690 | OK | OK | OK | |
| **EPSON** | Stylus Photo R2880 | OK | OK | OK | |
| **EPSON** | Stylus Photo TX700W | OK | OK | OK | |
| **EPSON** | Stylus Photo TX800FW | OK | OK | OK | |
| **EPSON** | Stylus Photo TX820FWD | OK | OK | OK | |
| **EPSON** | Stylus Pro 7600 | OK | OK | OK | OK |
| **EPSON** | Stylus TX550W | OK | OK | OK | |
| **EPSON** | Stylus TX420W | | OK | OK | |
| **EPSON** | Stylus TX410 | OK | OK | OK | |
| **EPSON** | Stylus TX430 | OK | OK | OK | |
| **EPSON** | Stylus TX235 | OK | OK | OK | |
| **EPSON** | Stylus TX220 | | OK | OK | |
| **EPSON** | Stylus TX200 | OK | OK | OK | |
| **EPSON** | Stylus TX210 | OK | OK | OK | |
| **EPSON** | Stylus TX130 | OK | OK | OK | |
| **EPSON** | Stylus TX110 | OK | OK | OK | |
| **EPSON** | Stylus TX100 | OK | OK | OK | |
| **EPSON** | Stylus T22 | OK | OK | OK | |
| **EPSON** | Stylus T20 | OK | OK | OK | |
| **EPSON** | Stylus T21 | OK | OK | OK | |
| **EPSON** | Stylus Photo T50 | OK | OK | OK | |
| **EPSON** | TM T70II | | OK | OK | |
| **EPSON** | TM T82III | | OK | OK | |
| **EPSON** | TM883（III） | OK | | | OK |
| **EPSON** | WorkForce AL-MX200DWF | OK | | | OK |
| **EPSON** | WorkForce AL-C300N | OK | OK | OK | OK |
| **EPSON** | WorkForce AL-C500DN | OK | OK | OK | |
| **EPSON** | WorkForce AL-M200DN | OK | OK | OK | |
| **EPSON** | WorkForce AL-M200DW | OK | OK | OK | |
| **EPSON** | WorkForce AL-M220DN | OK | OK | OK | |
| **EPSON** | WorkForce AL-M300D | OK | OK | OK | |
| **EPSON** | WorkForce AL-M300DN | OK | OK | OK | |
| **EPSON** | WorkForce AL-M310DN | OK | OK | OK | |
| **EPSON** | WorkForce AL-M320DN | OK | OK | OK | |
| **EPSON** | WorkForce AL-M400DN | OK | OK | OK | |
| **EPSON** | WorkForce Pro WF-C5290 | OK | OK | OK | |
| **EPSON** | WorkForce Pro WF-C5790 | OK | OK | OK | |
| **EPSON** | WorkForce Pro WF-C5890 | OK | OK | OK | |
| **EPSON** | WorkForce Pro WF-M5299 | OK | OK | OK | |
| **EPSON** | WorkForce Pro WF-M5799 | OK | OK | OK | |
| **EPSON** | WF-100 | OK | OK | OK | |
| **EPSON** | WF-2521 | OK | OK | OK | |
| **EPSON** | WF-2531 | OK | OK | OK | |
| **EPSON** | WF-2541 | OK | OK | OK | |
| **EPSON** | WF-2631 | OK | OK | OK | |
| **EPSON** | WF-2651 | OK | OK | OK | |
| **EPSON** | WF-2831 | OK | OK | OK | |
| **EPSON** | WF-2861 | OK | OK | OK | |
| **EPSON** | WF-3521 | OK | OK | OK | |
| **EPSON** | WF-3541 | OK | OK | OK | |
| **EPSON** | WF-3621 | OK | OK | OK | |
| **EPSON** | WF-3721 | OK | OK | OK | |
| **EPSON** | WF-5191 | OK | OK | OK | |
| **EPSON** | WF-5621 | OK | OK | OK | |
| **EPSON** | WF-6091 | OK | OK | OK | |
| **EPSON** | WF-7011 | OK | OK | OK | |

| | | | | | |
|---|---|---|---|---|---|
| **EPSON** | WF-7111 | OK | OK | OK | |
| **EPSON** | WF-7211 | OK | OK | OK | |
| **EPSON** | WF-7511 | OK | OK | OK | |
| **EPSON** | WF-7521 | OK | OK | OK | |
| **EPSON** | WF-7611 | OK | OK | OK | |
| **EPSON** | WF-7711 | OK | OK | OK | |
| **EPSON** | WF-8591 | OK | OK | OK | |
| **EPSON** | WF-R5691 | OK | OK | OK | |
| **EPSON** | WF-R8591 | OK | OK | OK | |
| **EPSON** | WP-4531 | OK | OK | OK | |
| **EPSON** | WP-4091 | OK | OK | OK | |
| **EPSON** | XP30 | OK | OK | OK | |
| **EPSON** | XP-102 | OK | OK | OK | |
| **EPSON** | XP-202 | OK | OK | OK | |
| **EPSON** | XP-225 | OK | OK | OK | |
| **EPSON** | XP-245 | OK | OK | OK | |
| **EPSON** | XP-302 | OK | OK | OK | |
| **EPSON** | XP-402 | OK | OK | OK | |
| **EPSON** | XP-422 | OK | OK | OK | |
| **EPSON** | XP-442 | OK | OK | OK | |
| **EPSON** | XP-701 | OK | OK | OK | |
| **EPSON** | XP-721 | OK | OK | OK | |
| **EPSON** | XP-2101 | OK | OK | OK | |
| **EPSON** | XP-4101 | OK | OK | OK | |
| **EPSON** | XP-15010 | OK | OK | OK | |
| **EPSON** | GP-C830 | OK | OK | OK | OK |
| **EPSON** | GP-M800 | OK | OK | OK | OK |
| **EPSON** | GP-C800 | OK | OK | OK | OK |
| **EPSON** | AL-C500 | OK | OK | OK | |
| **EPSON** | AL-C9300 | OK | OK | OK | |
| **EPSON** | TM-U220 | Parallel Only<br>USB Fail | Fail | Fail | OK |
| **Canon** | BJ-330 | OK | | | OK |
| **Canon** | BJC-4200 | OK | | | OK |
| **Canon** | BJC-4300 | OK | | | OK |
| **Canon** | BJC-4500 | OK | | | |
| **Canon** | BJC-4550 | OK | | | OK |
| **Canon** | BJC-4600 | OK | | | OK |
| **Canon** | BJF9000 | OK | OK | OK | |
| **Canon** | D380 | OK | OK | OK | |
| **Canon** | E400 | OK | OK | OK | |
| **Canon** | E600 | OK | OK | OK | |
| **Canon** | I-255 | OK | OK | OK | |
| **Canon** | I-355 | OK | OK | OK | |
| **Canon** | I-450 | OK | OK | OK | |
| **Canon** | I-455 | OK | OK | OK | |
| **Canon** | I-470D | OK | OK | OK | |
| **Canon** | I-475D | OK | OK | OK | |
| **Canon** | I-550 | OK | OK | OK | |
| **Canon** | I-560 | OK | OK | OK | |
| **Canon** | I-850 | OK | OK | OK | |
| **Canon** | I-865 | OK | OK | OK | |
| **Canon** | I-950 | OK | OK | OK | |
| **Canon** | I-6100 | OK | OK | OK | OK |
| **Canon** | I-6500 | OK | OK | OK | OK |
| **Canon** | I-9100 | OK | OK | OK | |
| **Canon** | I-9950 | OK | OK | OK | |
| **Canon** | IX4000 | OK | OK | OK | |
| **Canon** | IX5000 | OK | OK | OK | |
| **Canon** | IX6770 | OK | OK | OK | |
| **Canon** | Imageclass D380 | OK | OK | OK | |
| **Canon** | imageCLASS LBP223dw | OK | OK | OK | |
| **Canon** | imageCLASS LBP226dw | OK | OK | OK | |
| **Canon** | imageCLASS LBP228x | OK | OK | OK | |
| **Canon** | imageCLASS M236n | OK | OK | OK | |
| **Canon** | imageCLASS MF232W | OK | OK | OK | |
| **Canon** | imageCLASS MF429x | OK | OK | OK | |
| **Canon** | MP-160 | OK | OK | OK | |
| **Canon** | MP-638 | OK | OK | OK | |
| **Canon** | MP 770 | OK | OK | OK | |
| **Canon** | PIXMA G3000 | OK | OK | OK | |
| **Canon** | PIXMA MX318 | OK | OK | OK | |
| **Canon** | PIXMA MX320 | OK | OK | OK | |
| **Canon** | PIXMA MX357 | OK | OK | OK | |
| **Canon** | PIXMA MX377 | OK | OK | OK | |
| **Canon** | PIXMA MX397 | OK | OK | OK | |
| **Canon** | PIXMA MX416 | OK | OK | OK | |

| | | | | | |
|---|---|---|---|---|---|
| **Canon** | PIXMA MX457 | OK | OK | OK | |
| **Canon** | PIXMA MX477 | OK | OK | OK | |
| **Canon** | PIXMA MX497 | OK | OK | OK | |
| **Canon** | PIXMA MX527 | OK | OK | OK | |
| **Canon** | PIXMA MX700 | OK | OK | OK | |
| **Canon** | PIXMA MX727 | OK | OK | OK | |
| **Canon** | PIXMA MX927 | OK | OK | OK | |
| **Canon** | PIXUS IP2500 | OK | OK | OK | |
| **Canon** | PIXUS 990i | OK | OK | OK | |
| **Canon** | PIXMA E510 | OK | OK | OK | |
| **Canon** | PIXMA iP1000 | OK | OK | OK | |
| **Canon** | PIXMA iP1188 | OK | OK | OK | |
| **Canon** | PIXMA iP1700 | OK | OK | OK | |
| **Canon** | PIXMA iP1800 | OK | OK | OK | |
| **Canon** | PIXMA Ip1880 | OK | OK | OK | |
| **Canon** | PIXMA Ip1980 | OK | OK | OK | |
| **Canon** | PIXMA Ip2000 | OK | OK | OK | |
| **Canon** | PIXMA Ip2870 | OK | OK | OK | |
| **Canon** | PIXMA iP3000 | OK | OK | OK | |
| **Canon** | PIXMA Ip3300 | OK | OK | OK | |
| **Canon** | PIXMA Ip3500 | OK | OK | OK | |
| **Canon** | PIXMA Ip3680 | OK | OK | OK | |
| **Canon** | PIXMA iP4000 | OK | OK | OK | OK |
| **Canon** | PIXMA Ip4200 | OK | OK | OK | |
| **Canon** | PIXMA Ip4300 | OK | OK | OK | |
| **Canon** | PIXMA Ip4500 | OK | OK | OK | |
| **Canon** | PIXMA Ip4760 | OK | OK | OK | |
| **Canon** | PIXMA ip4970 | OK | OK | OK | |
| **Canon** | PIXMA Ip5000 | OK | OK | OK | |
| **Canon** | PIXMA Ip6000 | OK | OK | OK | |
| **Canon** | PIXMA Ip7270 | OK | OK | OK | |
| **Canon** | PIXMA Ip8500 | OK | OK | OK | |
| **Canon** | PIXMA Ip8770 | OK | OK | OK | |
| **Canon** | PIXMA MG2270 | OK | OK | OK | |
| **Canon** | PIXMA MG2470 | OK | OK | OK | |
| **Canon** | PIXMA MG2570 | OK | OK | OK | |
| **Canon** | PIXMA MG2580S | OK | OK | OK | |
| **Canon** | PIXMA MG2970 | OK | OK | OK | |
| **Canon** | PIXMA MG3070 | OK | OK | OK | |
| **Canon** | PIXMA MG3077 | OK | OK | OK | |
| **Canon** | PIXMA MG3170 | OK | OK | OK | |
| **Canon** | PIXMA MG3270 | OK | OK | OK | |
| **Canon** | PIXMA MG3570 | OK | OK | OK | |
| **Canon** | PIXMA MG3670 | OK | OK | OK | |
| **Canon** | PIXMA MG3680 | OK | OK | OK | |
| **Canon** | PIXMA MG4270 | OK | OK | OK | |
| **Canon** | PIXMA MG5470 | OK | OK | OK | |
| **Canon** | PIXMA MG5570 | OK | OK | OK | |
| **Canon** | PIXMA MG5670 | OK | OK | OK | |
| **Canon** | PIXMA MG6170 | OK | OK | OK | |
| **Canon** | PIXMA MG6270 | OK | OK | OK | |
| **Canon** | PIXMA MG6370 | OK | OK | OK | |
| **Canon** | PIXMA MG7170 | OK | OK | OK | |
| **Canon** | PIXMA MG7570 | OK | OK | OK | |
| **Canon** | PIXMA MP110 | OK | OK | OK | |
| **Canon** | PIXMA MP130 | OK | OK | OK | |
| **Canon** | PIXMA MP145 | OK | OK | OK | |
| **Canon** | PIXMA MP150 | OK | OK | OK | |
| **Canon** | PIXMA MP180 | OK | OK | OK | |
| **Canon** | PIXMA MP237 | OK | OK | OK | |
| **Canon** | PIXMA MP258 | OK | OK | OK | |
| **Canon** | PIXMA MP288 | OK | OK | OK | |
| **Canon** | PIXMA MP450 | OK | OK | OK | |
| **Canon** | PIXMA MP730 | OK | OK | OK | |
| **Canon** | PIXMA MP780 | OK | OK | OK | |
| **Canon** | PIXMA MP830 | OK | OK | OK | |
| **Canon** | PIXMA TS3170 | OK | OK | OK | |
| **Canon** | PIXMA TS3180 | OK | OK | OK | |
| **Canon** | PIXMA TS5070 | OK | OK | OK | |
| **Canon** | PIXMA TS8170 | OK | OK | OK | |
| **Canon** | S-200SPX | OK | OK | OK | |
| **Canon** | S-520 | OK | | | OK |
| **Lexmark** | C720 | OK | | | OK |
| **Lexmark** | E230 | OK | OK | OK | |
| **Lexmark** | E322 | OK | OK | OK | OK |
| **Lexmark** | Optra S1250 | OK | | | OK |
| **Lexmark** | P4350 | OK | OK | OK | |

| | | | | | |
|---|---|---|---|---|---|
| **Lexmark** | P6250 | OK | OK | OK | |
| **Lexmark** | T420 | OK | OK | OK | OK |
| **Lexmark** | T620 | OK | OK | OK | OK |
| **Lexmark** | W812 | OK | OK | OK | OK |
| **Lexmark** | Z42 | OK | OK | OK | |
| **Lexmark** | Z43 | OK | OK | OK | OK |
| **Lexmark** | Z45 | OK | OK | OK | |
| **Lexmark** | Z55 | OK | OK | OK | OK |
| **Lexmark** | Z515 | OK | OK | OK | OK |
| **Lexmark** | Z615 | OK | OK | OK | |
| **Lexmark** | Z705 | OK | OK | OK | OK |
| **FUJI Xerox** | Able 3321 | OK | | | OK |
| **FUJI Xerox** | DL700 | OK | | | OK |
| **FUJI Xerox** | DL900 | OK | | | OK |
| **FUJI Xerox** | DL-3400 | OK | | | OK |
| **FUJI Xerox** | DL-3800 | OK | | | OK |
| **FUJI Xerox** | DL-3850 | OK | | | OK |
| **FUJI Xerox** | DL-5800 | OK | | | OK |
| **FUJI Xerox** | DL-6400Pro | OK | | | OK |
| **FUJI Xerox** | DL-6800 | OK | | | OK |
| **FUJI Xerox** | DocuPrint 205 | OK | OK | OK | OK |
| **FUJI Xerox** | DocuPrint 2050 | OK | OK | OK | OK |
| **FUJI Xerox** | DocuPrint 240A | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint C1110B | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint C3055 | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint C3055dx | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint C4350 | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint C5005d | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint CM205 f | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint CP105 b | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint CP305d | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint P205 b | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint P215 b | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint P255 d | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint M115w | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint M115z | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint M205 b | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint M205 f | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint M205 fw | OK | OK | OK | |
| **FUJI Xerox** | DocuPrint P115w | OK | OK | OK | |
| **FUJI Xerox** | FP 410 | OK | | | OK |
| **FUJI Xerox** | Jet Wind 500C | OK | | | OK |
| **FUJI Xerox** | Phaser 3310 | OK | OK | OK | OK |
| **FUJI Xerox** | PP 10 | OK | | | OK |
| **Konica Minolta** | Bizhub 423 | | OK | OK | |
| **Konica Minolta** | Di 152 | OK | | | OK |
| **Konica Minolta** | Di 200/Di 250/Di 251 | OK | | | OK |
| **Konica Minolta** | magicolor 2450 | OK | OK | OK | OK |
| **Konica Minolta** | magicolor 5450 | OK | OK | OK | OK |
| **Konica Minolta** | magicolor 7300 | OK | OK | OK | |
| **Konica Minolta** | Magicolor 7300 | OK | OK | OK | |
| **Konica Minolta** | PagePro 1350W | OK | OK | OK | |
| **Konica Minolta** | PagePro 9100 | OK | OK | OK | |
| **Samsung** | CLP-315 | OK | OK | OK | |
| **Samsung** | CLP-500 | OK | OK | OK | OK |
| **Samsung** | CLP-510 | OK | OK | OK | OK |
| **Samsung** | CLP-620ND | OK | OK | OK | |
| **Samsung** | CLP-661NDK | OK | OK | OK | |
| **Samsung** | CLP-670NDK | OK | OK | OK | |
| **Samsung** | CLP-680ND | OK | OK | OK | |
| **Samsung** | CLP-775N | OK | OK | OK | |
| **Samsung** | CLX2160 | OK | OK | OK | |
| **Samsung** | ML-1510/1710 | OK | OK | OK | OK |
| **Samsung** | ML-1520 | OK | OK | OK | |
| **Samsung** | ML-1660 | OK | OK | OK | |
| **Samsung** | ML-1710 | OK | OK | OK | |
| **Samsung** | ML-1750 | OK | OK | OK | OK |
| **Samsung** | ML-1915 | OK | OK | OK | |
| **Samsung** | ML-2010 | OK | OK | OK | |
| **Samsung** | ML-2165W | OK | OK | OK | |
| **Samsung** | ML-2250 | OK | OK | OK | OK |
| **Samsung** | ML-2550 | OK | OK | OK | OK |
| **Samsung** | ML-2580N | OK | OK | OK | |
| **Samsung** | ML-2580NK | OK | OK | OK | |
| **Samsung** | ML-3471ND | OK | OK | OK | OK |
| **Samsung** | ML-4555N | OK | OK | OK | |
| **Samsung** | ML-5010ND | OK | OK | OK | |

| | | | | | |
|---|---|---|---|---|---|
| **Samsung** | ML-5015ND | OK | OK | OK | |
| **Samsung** | ML-8951N | OK | OK | OK | |
| **Samsung** | SL-M2620ND | OK | OK | OK | |
| **Samsung** | SCX-4016 | OK | OK | OK | OK |
| **Samsung** | SCX-4100/4106/4116/4216F | OK | OK | OK | OK |
| **Samsung** | SRP 270 | OK | | | OK |
| **Samsung** | Xpress SL-M2020 | OK | OK | OK | |
| **Samsung** | Xpress SL-M2020W | OK | OK | OK | |
| **Samsung** | ProXpress SL-M3820ND | OK | OK | OK | |
| **Panasonic** | KX-MB1500TW | OK | OK | OK | |
| **Panasonic** | KX-MB1520TW | OK | OK | OK | |
| **Panasonic** | KX-MB1530TW | OK | OK | OK | |
| **Panasonic** | KX-P1121 | OK | | | OK |
| **Panasonic** | KX-P1123 | OK | | | OK |
| **Panasonic** | KX-P1124 | OK | | | OK |
| **Panasonic** | KX-P1624 | OK | | | OK |
| **Panasonic** | KX-P6500 | OK | | | OK |
| **TOSHIBA** | Estudio-25 | OK | | | OK |
| **NEC** | NEC P2200 | OK | | | OK |
| **NEC** | NEC P3200 | OK | | | OK |
| **NEC** | NEC P5300 | OK | | | OK |
| **NEC** | NEC P8000 | OK | | | OK |
| **IBM** | IBM InforP 20 | OK | | | OK |
| **IBM** | InfoP 1116 | OK | OK | OK | OK |
| **IBM** | InfoP 1312 | OK | OK | OK | OK |
| **IBM** | InfoP 1316 | OK | OK | OK | OK |
| **IBM** | InfoP 1332 | OK | OK | OK | OK |
| **IBM** | InfoP 1412 | OK | OK | OK | OK |
| **Star** | NX-2420 | | | | OK |
| **Sharp** | AR-255 | OK(Parallel only) | | | OK(Parallel only) |
| **Sharp** | AR-265FG | OK(Parallel only) | | | OK(Parallel only) |
| **Sharp** | AR-M160(AR-NB2) | OK(Parallel only) | | | OK(Parallel only) |
| **Sharp** | AR-M205 | OK(Parallel only) | | | OK(Parallel only) |
| **Sharp** | AR-M207 | OK(Parallel only) | | | OK(Parallel only) |
| **Sharp** | AR-M235 | OK(Parallel only) | | | OK(Parallel only) |
| **Sharp** | AR-M275 | OK(Parallel only) | | | OK(Parallel only) |
| **Sharp** | AR-M350 | OK(Parallel only) | | | OK(Parallel only) |
| **Sharp** | AR-M400 | OK(Parallel only) | | | OK(Parallel only) |
| **Sharp** | AR-M450 | OK(Parallel only) | | | OK(Parallel only) |
| **RICOH** | NF3570 | OK | | | OK |
| **RICOH** | Afcio MP 1600 | OK | OK | OK | |
| **RICOH** | Afcio MP 3350 | OK | OK | OK | |
| **RICOH** | Afcio MP 5001 | OK | OK | OK | |
| **RICOH** | Afcio MP 6002 | OK | OK | OK | |
| **RICOH** | Afcio MP 7502 | OK | OK | OK | |
| **RICOH** | Afcio MP 9002 | OK | OK | OK | |
| **RICOH** | Afcio MP C2030 | OK | OK | OK | |
| **RICOH** | Afcio MP C2050 | OK | OK | OK | |
| **RICOH** | Afcio MP C3001 | OK | OK | OK | |
| **RICOH** | Afcio MP C3504 | | OK | OK | |
| **RICOH** | Afcio MP C4000 | OK | OK | OK | |
| **RICOH** | Afcio MP C5501A | OK | OK | OK | |
| **RICOH** | Afcio MP C5000 | OK | OK | OK | |
| **RICOH** | Afcio SP 3510SF | OK | OK | OK | |
| **RICOH** | Afcio SP C420DN | OK | OK | OK | |
| **RICOH** | Gestetner MP 2001SP | OK | OK | OK | |
| **RICOH** | Gestetner MP 2501SP | OK | OK | OK | |
| **RICOH** | Gestetner MP 2554SP | OK | OK | OK | |
| **RICOH** | Gestetner MP 3054SP | OK | OK | OK | |
| **RICOH** | Gestetner MP 3554SP | OK | OK | OK | |
| **RICOH** | Gestetner MP 4054SP | OK | OK | OK | |
| **RICOH** | Gestetner MP 5054SP | OK | OK | OK | |
| **RICOH** | Gestetner MP 6054SP | OK | OK | OK | |
| **RICOH** | MP C2003SP | OK | OK | OK | |
| **RICOH** | MP C2503SP | OK | OK | OK | |
| **RICOH** | MP C3003SP | OK | OK | OK | |
| **RICOH** | MP C3503SP | OK | OK | OK | |
| **RICOH** | MP C4503SP | OK | OK | OK | |
| **RICOH** | MP C2003SP | OK | OK | OK | |

| | | | | | |
|---|---|---|---|---|---|
| **Brother** | MFC 1815 | OK | OK | OK | |
| **Brother** | MFC 1910W | OK | OK | OK | |
| **Brother** | MFC 4800 | OK | OK | OK | OK |
| **Brother** | MFC 4800J | OK | OK | OK | OK |
| **Brother** | MFC 6800 | OK | OK | OK | OK |
| **Brother** | MFC 7220 | OK | OK | OK | OK |
| **Brother** | MFC 7420 | OK | OK | OK | OK |
| **Brother** | MFC 7820N | OK | OK | OK | OK |
| **Brother** | MFC 8840D | OK | OK | OK | OK |
| **Brother** | MFC 210C | OK | OK | OK | |
| **Brother** | MFC 240C | OK | OK | OK | |
| **Brother** | MFC-J200 | OK | OK | OK | |
| **Brother** | MFC-J2320 | OK | OK | OK | |
| **Brother** | MFC-J3520 | OK | OK | OK | |
| **Brother** | MFC-J430W | OK | OK | OK | |
| **Brother** | MFC-J825DW | OK | OK | OK | |
| **Brother** | DCP-1510 | OK | OK | OK | |
| **Brother** | DCP-1511 | OK | OK | OK | |
| **Brother** | DCP-J100 | OK | OK | OK | |
| **Brother** | DCP-J105 | OK | OK | OK | |
| **Brother** | DCP-7030 | OK | OK | OK | |
| **Brother** | DCP-L2540DW | OK | OK | OK | |
| **Brother** | DCP-T520w | OK | OK | OK | |
| **Brother** | HL-1110 | OK | OK | OK | |
| **Brother** | HL-1210W | OK | OK | OK | |
| **Brother** | HL-1260 | OK | | | OK |
| **Brother** | HL-2040 | OK | | | |
| **Brother** | HL-2140 | OK | OK | OK | |
| **Brother** | HL-2170W | OK | OK | OK | |
| **Brother** | HL-2240D | OK | OK | OK | |
| **Brother** | HL-L2320D | OK | OK | OK | |
| **Brother** | HL-L2380dw | OK | OK | OK | |
| **Brother** | HL-L2395dw | OK | OK | OK | |
| **Brother** | HL-L2460dw | OK | OK | OK | |
| **Brother** | HL-3170CDW | OK | OK | OK | |
| **Brother** | HL-L5210dn | OK | OK | OK | |
| **Brother** | HL-L5210dw | OK | OK | OK | |
| **Brother** | HL-L5215dn | OK | OK | OK | |
| **Brother** | HL-L6210dw | OK | OK | OK | |
| **Brother** | HL-L6400dw | OK | OK | OK | |
| **Brother** | HL-L6415dw | OK | OK | OK | |
| **Brother** | IntelliFax 2820 | OK | OK | OK | |
| **OKI** | Microline 391 | | | | OK |
| | Microline 5100FB | | | | OK |
| | B4350 | OK | OK | OK | OK |
| | ES5112 | OK | OK | OK | |
| **MITAC** | MP-6600C | | | | OK |
| **BENQ** | BENQ CM3000 | OK | OK | OK | |
| **Avision** | MF 3200 | OK | OK | OK | |
| | MF 3230 | OK | OK | OK | |
| **Citizen** | GSX230 | OK | | | OK |
| **DOCUJET** | 1610F | OK | OK | OK | OK |
| | UA1610 | OK | OK | OK | OK |
| **FUTEK** | F8000 | OK | | | OK |
| | F9000 | OK | | | OK |
| | F70 | OK | | | OK |
| | F80 | OK | | | OK |
| | F84+ | OK | | | OK |
| | F86+ | OK | | | OK |
| | F90 | OK | | | OK |
| | F93 | OK | | | OK |
| | F94 | OK | | | OK |
| | F95 | OK | | | OK |
| | F96 | OK | | | OK |
| | F97 | OK | OK | OK | OK |
| **Kyocera** | FS-1010 | OK | OK | OK | OK |
| | FS-1010KX | OK | OK | OK | |
| | FS-1020 | OK | OK | OK | OK |
| | FS-1920 | OK | OK | OK | OK |
| | FS-2000D | OK | OK | OK | OK |
| | FS-820 | OK | OK | OK | OK |
| | FS-920 | OK | OK | OK | OK |
| | FS-6020 | OK | OK | OK | OK |
| | FS-6026 | OK | OK | OK | OK |
| | ECOSYS M2540dn | OK | OK | OK | |
| | ECOSYS M2635dn | OK | OK | OK | |
| | ECOSYS P-3045dn | OK | OK | OK | |

| | | | | | | |
|---|---|---|---|---|---|---|
| | ECOSYS P-3050dn | OK | OK | OK | | |
| | ECOSYS P-3055dn | OK | OK | OK | | |
| | TASKalfa 180 | OK | OK | OK | | |
| | TASKalfa 180GX | OK | OK | OK | | |
| | TASKalfa 2552ci | OK | OK | OK | | |
| | TASKalfa 3212 | OK | OK | OK | | |
| **TSC** | TC200 | OK | | | | |
| | TTP-245+ | OK | | | OK | Only support parallel |
| | TTP-343+ | OK | OK | OK | | |
| | TDP-225 | OK | OK | OK | | |
| | TTP-2410M | OK | | | OK | Only support parallel |
| | TTP-243E | OK | | | OK | Only support parallel |
| | TTP-244+ | OK | OK | OK | | |
| | TTP-244CE | OK | OK | OK | | |
| | TTP-245C | OK | OK | OK | | |
| | TTP-247 | OK | | | OK | Only support parallel |
| | TTP-342M+ | OK | | | OK | Only support parallel |
| | TTP-344M | OK | | | OK | Only support parallel |
| | TTP-344M+ | OK | | | OK | Only support parallel |
| | TTP-345 | | | | OK | |
| **Zebra** | S4M | | | | OK | |
| | ZP450 | OK | OK | OK | | |
| | ZP500 Plus | OK | OK | OK | | |
| | ZT230 | OK | OK | OK | | |
| **LEDOMARDS** | LP-8000A | | OK | OK | | |
| | LP-7800IV | | OK | OK | | |
| | LP-3000 | | OK | OK | | |
| | LP-2000 | | OK | OK | | |
| | LP-1000 | | OK | OK | | |
| | LP-7580 | OK | | | OK | Only support parallel |
| | LP-7800 | OK | | | OK | Only support parallel |
| | LP-7800III | OK | | | OK | Only support parallel |
| | LP-8000/8000S | OK | | | OK | Only support parallel |
| **ARGOX** | CP-3140L | OK | | | | |
| | IX4-350 | | OK | OK | | |
| | X-3200 | OK | OK | OK | | Only support USB |
| **SATO** | CL412E | OK | | | OK | |
| | CG408 | OK | | | OK | Only support parallel |
| | CL408e | OK | | | OK | |
| RING | 412PEI+ | OK | OK | OK | | |
| HPRT | SL41 | OK | OK | OK | | |
| Xprinter | XP-490B | OK | OK | OK | | |