



GE-CT 18 Li - Solo

Cordless Lawn Trimmer

Item No.: 3411172

Ident No.: 11047

Bar Code: 4006825588255

The GE-CT 18 Li Solo cordless grass trimmer is a powerful tool which helps you keep your lawn looking immaculate in those places which cannot be reached by a lawn mower. Thanks to its low weight and handy size the tool provides good service for the trimming of large grounds and allotments where there is no connection to the electric power grid.

Features

- Member of the Power X-Change family, 1x18V batteries necessary
- Infinitely adjustable second handle
- Telescopic long handle, infinitely adjustable
- Motor head rotateable +/- 90° for vertical surfaces + lawn edges
- Motor head can be tilted to 5 settings
- Flower guard
- Compartment for 20 blades integrated in second handle
- Incl. 20 plastic blades
- Soft grip
- Supplied without battery and charger (available separately)

Technical Data

- | | |
|--------------------------|----------|
| - Revolutions of knife | 8500 rpm |
| - Cutting width of knife | 24 cm |

Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight | 1.75 kg |
| - Gross weight single packaging | 2.4 kg |
| - Dimensions single packaging | 960 x 190 x 110 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight export carton | 10.86 kg |
| - Dimensions export carton | 980 x 395 x 240 mm |
| - Container quantity (20"/40"/40"HC) | 1044 2160 2400 |



Available as special accessories



Ersatzmesser-Set GE-CT 18 Li
Lawn Trimmer Accessory
Item No.: 3405730
Bar Code: 4006825560404
Einhell Grey



18V 2,0 Ah Power-X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

20V/1,5 Ah Gardol PXC Starter
PXC-Starter-Kit
Item No.: 4512038
Bar Code: 4006825611472
Gardol



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 30min Power-X-Change
PXC-Charger
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory



18V 3,0 Ah Power-X-Change
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory