



Installation Guide


1. Package Contents



Switch x 1



Quick Installation Guide x 1




Power Cord x 1




Mounting Accessories
(hook x 2; Mats x 4; screw x 8)

2. Appearance Overview

• Front panel




• Back panel




• LED indicator

LED	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. On: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
Link	Green	Off: not connected to the network equipment On: connected to 10/100/1000Mbps devices Blinking: connected devices are data transmission

• Front panel




• Back panel




• LED indicator

LED	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. On: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
Link	Green	Off: not connected to the network equipment On: connected to 10/100/1000Mbps devices Blinking: connected devices are data transmission

• Front panel




• Back panel




• LED indicator

LED	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. On: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
Link/Act	Green	Off: not connected to the network equipment On: connected to 10/100/1000Mbps devices Blinking: connected devices are data transmission

• Front panel




• Back panel




• LED indicator

LED	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. On: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
Link/Act	Green	Off: not connected to the network equipment On: connected to 10/100/1000Mbps devices Blinking: connected devices are data transmission

• Front panel




• Back panel




• LED indicator

LED	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. On: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
1000M	Green	Off: There is no connected device or the connected device is 100M On: connected to 1000Mbps devices Blinking: connected devices are data transmission
Link/Act	Green	Off: not connected to the network equipment On: connected to 10/100/1000Mbps devices Blinking: connected devices are data transmission

• Front panel




• Back panel



• LED indicator

LED	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. On: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
1000M	Green	Off: There is no connected device or the connected device is 100M On: connected to 1000Mbps devices Blinking: connected devices are data transmission
Link/Act	Green	Off: not connected to the network equipment On: connected to 10/100/1000Mbps devices Blinking: connected devices are data transmission

• Front panel




• Back panel




• LED indicator

LED	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. On: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
1000M	Green	Off: There is no connected device or the connected device is 100M On: connected to 1000Mbps devices Blinking: connected devices are data transmission
Link/Act	Green	Off: not connected to the network equipment On: connected to 10/100/1000Mbps devices Blinking: connected devices are data transmission

• Front panel



• Back panel



• LED indicator

LED	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. On: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
1000M	Green	Off: There is no connected device or the connected device is 100M On: connected to 1000Mbps devices Blinking: connected devices are data transmission
Link/Act	Green	Off: not connected to the network equipment On: connected to 10/100/1000Mbps devices Blinking: connected devices are data transmission

Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

• If the product defects within three months after purchase, we will provide you a new product of the same model.
• If the product defects within the three-year warranty period, we will provide the professional maintenance service.
• Proof of purchase and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
• Any other defects that are not caused by workmanship or product quality, such as natural disaster, water damage, extreme thermal or environmental conditions, sticker damaged, warranty card losing will disqualify the product from limited warranty.

