PL MYSZ PRZEWODOWA

1. Informacje o bezpieczeństwie
Aby zapewnić bezpieczne użytkowanie produktu, należy przestrzegać poniższych zaleceń:
• Używaj zgodnie z przeznaczeniem – mysz jest przeznaczona do użytku z komputerami osobistymi i innymi kompatybilnymi urządzeniami.
• Nie demontuj urządzenia – ingerencja w konstrukcję może prowadzić do awarii lub zagrożenia dla użytkownika.
• Chroń przed wilgocią – nie wystawiaj myszy na działanie wody ani innych płynów.
• Unikaj przegrzewania – nie umieszczaj myszy w pobliżu źródeł ciepła ani w bezpośrednim świetle słonecznym.
• Nie dopuszczaj do uszkodzeń kabla – unikaj zaginania, ściskania lub uszkadzania przewodu zasilającego, co może prowadzić do awarii lub zagrożenia elektrycznego.

2. Instrukcje użytkowania
• Podłącz mysz do odpowiedniego portu USB w komputerze.
• Upewnij się, że komputer wykrył urządzenie i sterowniki zostały poprawnie zainstalowane.
• Urządzenie działa jako interfejs HID, co oznacza, że jest automatycznie rozpoznawane przez system operacyjny i nie wymaga instalacji dodatkowych dedykowanych sterowników.
• Nie używaj myszy mokrymi rękami ani na niestabilnej powierzchni.
• Jeśli mysz nie działa poprawnie, odłącz ją i ponownie podłącz do innego portu USB.

3. Instrukcje dotyczące konserwacji
• Czyść mysz miękką, suchą szmatką lub delikatnie zwilżoną ściereczką.
• Nie używaj środków chemicznych, które mogą uszkodzić powierzchnię.
• Regularnie sprawdzaj przewód pod kątem uszkodzeń.

4. Ostrzeżenia dotyczące bezpieczeństwa
⚠ **OSTRZEŻENIE:**
• Mysz nie jest zabawką – nie pozostawiaj jej w zasięgu małych dzieci.
• Nie używaj uszkodzonej myszy – może to powodować zagrożenie dla użytkownika.
• Długotrwałe użytkowanie może powodować zmęczenie rąk – rób przerwy co 30–60 minut, aby uniknąć nadwyrężenia nadgarstków.

5. Informacje dodatkowe
Aby zapewnić bezpieczne użytkowanie produktu, należy przestrzegać poniższych zaleceń:
• Nie ciągnąć ani nie zginać kabla nadmiernie, aby uniknąć uszkodzenia przewodu.
• Nie używać w wilgotnym środowisku ani nie narażać na kontakt z wodą.
• Nie otwierać obudowy myszki – grozi to uszkodzeniem urządzenia i utratą gwarancji.
• Podłączać wyłącznie do kompatybilnych portów USB, aby uniknąć przeciążeń.
• Przechowywać poza zasięgiem małych dzieci, aby zapobiec ryzyku połknięcia małych elementów.

CE

Symbol przekreślonego kosza na śmieci umieszczany na sprzęcie, opakowaniu lub dokumentach do niego dołączonych oznacza, że produktu nie wolno wyrzucać łącznie z innymi odpadami. Zużyty sprzęt może zawierać substancje posiadające właściwości trujące i rakotwórcze, niebezpieczne dla zdrowia i życia ludzi, ponadto zatruwające glebę oraz wody gruntowe. Obowiązkiem użytkownika jest przekazanie zużytego sprzętu do wyznaczonego punktu zbiórki w celu właściwego jego przetworzenia. Więcej informacji na temat punktów utylizacji urządzeń można uzyskać od władz lokalnych, firm utylizacyjnych oraz w miejscu zakupu tego produktu. Gospodarstwo domowe spełnia ważną rolę w przyczynianiu się do ponownego użycia i odzysku surowców wtórnych, w tym recyclingu, zużytego sprzętu. Na tym etapie kształtuje się postawy, które wpływają na zachowanie wspólnego dobra jakim jest czyste środowisko naturalne.

Producent:
Megabajt Sp. z o.o., ul. Rydygiera 8
01-793-Warszawa, Polska
e-mail: info@megabajt.com.pl, tel: +48 22 560 73 00
Wyprodukowano w Chinach

EN WIRED MOUSE

1. Safety Information

To ensure safe use of the product, please follow these guidelines:

- Use as intended – The mouse is designed for use with personal computers and other compatible devices.
- Do not disassemble the device – Tampering with the structure may cause malfunction or pose a safety risk.
- Protect from moisture – Do not expose the mouse to water or other liquids.
- Avoid overheating – Do not place the mouse near heat sources or in direct sunlight.
- Prevent cable damage – Avoid bending, squeezing, or damaging the power cord, as it may cause malfunctions or electrical hazards.

2. User Instructions

- Connect the mouse to the appropriate USB port on your computer.
- Ensure that the computer detects the device and the drivers are correctly installed.
- The device functions as an HID interface, meaning it is automatically recognized by the operating system and does not require the installation of additional dedicated drivers.
- Do not use the mouse with wet hands or on an unstable surface.
- If the mouse does not function properly, unplug it and reconnect it to a different USB port.

3. Maintenance Instructions

- Clean the mouse with a soft, dry cloth or a slightly damp cloth.
- Do not use chemical agents that may damage the surface.
- Regularly inspect the cable for any signs of damage.

4. Safety Warnings

⚠ **WARNING:**

- The mouse is not a toy – Keep it out of reach of small children.
- Do not use a damaged mouse – It may pose a risk to the user.
- Prolonged use may cause hand fatigue – Take breaks every 30–60 minutes to avoid wrist strain.

5. Additional Information

To ensure safe product use, follow these guidelines:

- Do not excessively pull or bend the cable to prevent damage.
- Do not use in humid environments or expose it to water.
- Do not open the mouse casing – This may result in device damage and void the warranty.
- Connect only to compatible USB ports to avoid overloading.
- Store out of reach of small children to prevent choking hazards.



CE



The symbol of a crossed-out wheeled bin placed on electronic or electrical equipment, its packaging or accompanying documents means that the product may not be thrown out together with other waste. Used equipment may contain substances with toxic and carcinogenic properties, hazardous to human health and life, and poisoning the soil and groundwater. It is the user's responsibility to hand over the used equipment to a designated collection point for its proper processing. For more information on recycling of electronic and electrical equipment, please contact your local authorities, waste disposal services and the place where you purchased this product.
The household plays an important role in contributing to the reuse and recovery of secondary raw materials, including recycling, waste equipment. At this stage, attitudes are formed that affect the preservation of the common good, which is a clean natural environment.

Manufacture:
Megabajt Sp. z o.o., ul. Rydygiera 8
01-793-Warszawa, Poland
e-mail: info@megabajt.com.pl, phone: +48 22 560 73 00
Made in China.