


CARSON®

GN-55

MAGNILAMP™

2x FLEXIBLE ARM LIGHTED MAGNIFIER

Instructions for Use:



Installing Batteries

Pull open battery door (Fig. 1). Insert 2 AA batteries and replace battery door (Fig. 2). Make sure to follow polarity indicators marked inside battery compartment. Replace battery door (Fig. 3).




Fig. 1




Fig. 2




Fig. 3

Warning: Do not mix old and new batteries, batteries with different brand names or different types within brands. Different attributes may cause the battery to leak fluid, overheat or explode. Do not expose to fire or excessive heat. Inspect all batteries for signs of corrosion or leakage. Use alkaline batteries only, rechargeable batteries not recommended. Insert all batteries in the direction indicated.

To Activate LED Light

To turn light on, slide switch (located on side of magnifier handle) forward (Fig. 4).







Fig. 4


To Use Hands-Free

Snap adapter into base. Please note that adapter is "keyed" to fit only one way (Fig. 5). Place magnifier handle into adapter. It is also keyed and will easily "click-lock" into base when correctly inserted (Fig. 6). Adjust flexible arm to position lens and light as needed (Fig. 7).



To Remove Magnifier From Base

Lift lock tab outward and lift magnifier from base (Fig. 8) to use as hand-held magnifier.



CAUTION - FIRE HAZARD:

Keep magnifier away from direct sunlight to prevent accidental fire.

Customer Service:

If you experience any difficulties, please contact us and we will be happy to help you.

In the U.S.A.

Phone: 1-631-963-5000

Email: info@carson.com

In the U.K.

Phone: +44 (0) 1938 557440

Email: uksupport@carson.com

In the E.U.

Phone: +44 (0) 1938 557440

Email: eusupport@carson.com

For warranty information, visit www.carson.com/warranty