

Arx 500 Core

ACCESSORIES

A



x3

B



x1

C



x13

D



x22

E



x6

F



x20

G



x1

ZIP TIE



x6

FANS




x2

STRATUS 140 PWM (PREINSTALLED)



x1

PWM SPLITTER




x1

5x PWM 4-PIN



x1

1. Overview



1x 2.5"/3.5" (HYBRID)
6x 2.5" (SSD)



PSU MAX:
300 mm

REAR



1x 120/140 FAN



120 RAD

BOTTOM



1x 120 FAN

TOP



2x 120 FAN
2x 140 FAN



120/240/
280 RAD

FRONT



3x 120 FAN
3x 140 FAN



120/240/
280/360 RAD

TOP FILTER

PSU FILTER

MESH FRONT

I/O

To connect I/O panel of the case to motherboard please use your motherboard manual.

1 Power button

2 Power LED

3 HDD LED

4 Reset button


5 USB port

6 Microphone port


7 Headphones port

8 USB port


9 USB-C port



2. Panel removal




3. Hardware installation



Four UNC-6-32 screws should be included with the PSU.

4. Hardware installation



Use (B) to securely screw additional (A) parts into designated places.



CUSTOMER SERVICE TELEPHONE:
+48 222920130 +44 3333394929
Call charges will apply according to your operator's rates.

NEED MORE INFORMATION?
[ENDORFY.COM/KB/EY2A016](https://www.endorfy.com/kb/EY2A016)



Arx 500 Core

5. Hardware installation

C x8

D x6

E x6

F x4

G x1

HDD




x6

TOP VIEW



BOTTOM VIEW



SSD



x4

TOP VIEW



BOTTOM VIEW



SSD




x4

TOP VIEW




BOTTOM VIEW






6. Dust filters



7. Fan connection



CUSTOMER SERVICE TELEPHONE:
+48 222920130 +44 3333394929
Call charges will apply according to your operator's rates.

NEED MORE INFORMATION?
[ENDORFY.COM/KB/EY2A016](https://www.endorfy.com/kb/EY2A016)



