


SOL-R FLIGHTSTICK


PC (Windows® 10/11)

INSTRUCTION MANUAL
MANUEL D'INSTRUCTIONS

USER MANUAL - MANUEL DE L'UTILISATEUR



<https://support.thrustmaster.com/product/sol-r-flightstick>






LEFT
HANDED



RIGHT
HANDED

A B


C D











1 


2 


3 


4 





6 


1 


2 



3 

4 

5 

7 

8 



5081188