

VIVO◇LINK®
X10
Bring Sound to Life

50W High Power Subwoofer




Parameter

Model	X10	F.R	60Hz~18KHz
BT version	5.0	Distortion	≤3%
BT range	≥10M (Open field)	Speaker unit	66*66MM
Speaker power	50W	Play time	10H(50% volume)
Battery	7.3V/2600mAh	Charging time	≤4H
Input power	Type-C 5V/2A	Product Size	225.85*74*96.9MM

Accessories





AUX cable



Type-C cable

Key Function



- ① Status Indicator
- ② Sound effect indicator
- ③ Play / Pause / Answer / Hang up
- ④ Volume down / Previous track
- ⑤ Volume up / Next track
- ⑥ Phone assistant wake up
- ⑦ Power on / off
- ⑧ Sound effect/mode switching
- ⑨ Microphone
- ⑩ Type-C charging
- ⑪ TF card
- ⑫ AUX in

BUTTON	OPERATING	FUNCTION DESCRIPTION
	Short press	1. In the off state, short press to turn on 2. In the on state, short press to turn off
	Double click	In the state of Bluetooth to be connected, double-click to enter/exit TWS pairing mode
	Short press	Play mode switching: Bluetooth, AUX, TF card
	Long press	Sound switching: pop, vocal, heavy bass
	Short press	1. Music playback status: play, pause function 2. Call status: short press to connect 3. When the call is answered, short press to hang up 4. When the phone's Bluetooth is connected: Double-click quickly to call back the last call made by the phone

	Long press	1. Bluetooth connection status: long press for 3s to disconnect 2. When there is an incoming call: long press for 2s to reject
	Short press	Volume down, total 16 levels
	Long press	Previous track (This function is not available in AUX mode)
	Short press	Volume up, total 16 levels
	Long press	Next track (This function is not available in AUX mode)
	Short press	Bluetooth connection status: short press to wake up phone voice assistant
	Long press	Bluetooth connection status: long press 5S to factory reset

LED indicator

① Status indicator
(Above the "⏻" key)

- The blue light flashes quickly when Bluetooth is ready to pair; The blue light is always on when Bluetooth is connected
- When the AUX / TF card is playing, the blue light flashes slowly

② Sound effect indicator
(Above the "M" key)

- Press and hold for 2s to switch sound effects;
- A white light is on: Pop
Two white lights: Vocal
Three white lights on: Heavy bass

TF /Cable playback

- Bluetooth speaker supports reading up to 64GB TF card
Supports music format: APE / FLAC / WAV / MP3
- Insert the TF card into the card slot and automatically play the audio file after recognition
- AUX, Type-C cable can be inserted into the device to play; if it is connected with Bluetooth, please press the "M" key to switch to the audio cable playback mode

TWS pairing

- Power on the two speakers (if a Bluetooth device is connected, you must first disconnect the Bluetooth connection)
- Double-click one of the "⏻" keys to enter TWS pairing mode
- After the TWS is successfully paired, there will be a beep. At this time, the yellow indicators of the two speakers are on
- Turn on the Bluetooth function of the mobile phone or other Bluetooth device, find and connect the Bluetooth named "Vivolink X10"
- TWS paired successfully, the machine will automatically perform TWS pairing each time after turning on the machine, no need to repeat the operation
- If the machine has been paired with TWS, please press and hold the 5s "⏻" key to reset; After the reset is successful, restart the machine, and then refer to 1 ~ 4 above to complete the TWS pairing
- In TWS mode, only the main speaker has hands-free function, and the sub speaker is silent during a call
- In TWS mode, you can still switch sound effects

Warranty card

Dear customer, thank you for purchasing our products In order to serve you better, please keep this warranty card in a safe place		
Maintenance records	Date	Malfunctions and causes
Product		
Model		
Your name		
Your phone		
Purchase date		
Your address		