







U-COM 16

Quick guide





Voice commands	
Action	Command
Start Mesh intercom	Hey Interphone, Mesh On
Stop Mesh intercom	Hey Interphone, Mesh Off
Set Open Mesh mode	Hey Interphone, Open Mesh
Set private Mesh mode	Hey Interphone, Group Mesh
Group creation for private Mesh	Hey Interphone, Mesh Grouping


Voice commands	
Action	Command
Bluetooth® intercom pairing	Hey Interphone, Pairing Intercom
Connect intercom one	Hey Interphone, Intercom one
Connect intercom two	Hey Interphone, Intercom two
Connect intercom three	Hey Interphone, Intercom three
Stop intercom	Hey Interphone, end Intercom

Voice commands	
Action	Command
Phone pairing	Hey Interphone, phone pairing
Answer a phone call	Hello
Reject a phone call	Ignore
Start Google assistant	Hey Google
Start Siri	Hey Siri


Voice commands	
Action	Command
Music play via Bluetooth®	Hey Interphone, play music
Music stop	Hey Interphone, stop music
Start FM radio	Hey Interphone, FM radio on
Stop FM Radio	Hey Interphone, FM radio off
Track/Station next	Hey Interphone, next
Track/Station previous	Hey Interphone, previous
Check battery level	Hey Interphone, check battery
Increase listening volume	Hey Interphone, volume up
Decrease listening volume	Hey Interphone, volume down

Bluetooth® devices pairing



Main phone pairing (to be done with unit on)



Second phone pairing (to be done with unit on)




Gps SATNAV & TFT pairing (to be done with unit on)



Phone

Incoming call answer End call Reject incoming call




Phone assistant trigger Speed dial



Music and FM radio

Music play Music pause Next track Previous track



Start/stop music sharing Start/stop FM radio




Next station Previous station




Mesh Intercom - OPEN MESH

OPEN MESH mode (default) Start/stop intercom OPEN MESH Intercom connection OPEN MESH




Change intercom channel OPEN MESH (1>2>3>4>5>6>7>8>9>Exit>1>2>...)




Mesh Intercom - GROUP MESH

GROUP MESH mode




Bluetooth® Intercom - pairing

Intercom pairing 2 units Intercom pairing 3 units Intercom pairing 4 units




Bluetooth® Intercom - conference

Intercom conference Intercom group conference




Bluetooth® Intercom - other pairings

Other Interphone series pairing (to be done with unit OFF)



Anycom pairing for other brands (except Sena)



Setup

