



Einhell

PROFESSIONAL



Cordless Demolition Hammer

TP-DH 18/4 Li BL - Solo

Item No.: 4514190

Ident No.: 21014

Bar Code: 4006825680645

The Einhell Professional Cordless Demolition Hammer TP-DH 18/4 Li BL-Solo is ideal for light chiselling and demolition tasks. With 4.0 J impact force, constant electronics, flexible battery power, adjustable impact rate, and a continuous operation lock, it removes concrete ridges, tiles, or plaster, making it perfect for renovations. Powered by an Einhell brushless motor for greater power and longer runtime. A 10-year motor warranty applies upon online registration. Thanks to the SDS-Plus chuck, chisels can be quickly changed and adjusted to 16 different positions. Includes pointed and flat chisels, plus E-Case. Battery and charger not included.

Features & Benefits

- Part of the Power X-Change family, 1x 18 V battery required
- Brushless motor – more power and longer running time
- Brushless – 10-year motor warranty with registration
- Compact, powerful demolition hammer for light chiseling work
- Variable impact rate control for material-specific work
- Vibration-damped handle for optimal use
- Flexibly adjustable auxiliary handle for more comfortable work
- 16-step chisel adjustment
- SDS-plus chuck with semi-automatic system
- Continuous operation lock for time-intensive tasks
- Integrated LED light to illuminate the work area
- Includes 1x pointed chisel and 1x flat chisel
- Delivered in a transport and storage case E-Case
- Comes without battery or charger (sold separately)



Technical Data

- | | |
|----------------|--------------------------|
| - Voltage | 18 V |
| - Impact rate | 0-4600 min ⁻¹ |
| - Impact power | 4 J |
| - Tool holder | SDS-plus |



COMPACT & LIGHTWEIGHT



ANTI-VIBRATION



Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight (kg) | 2.88 |
| - Gross weight (kg) | 5.08 |
| - Dimensions single packaging | 441 x 328 x 130 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight of export carton | 24 kg |
| - Dimensions export carton | 540 x 455 x 345 mm |
| - Container quantity (20"/40"/40"HC) | 1280 2640 3080 |



Available as special accessories



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



E-Case L with wheels
System Carrying Case
Item No.: 4540014
Bar Code: 4006825660562
Einhell Accessory



E-Case S-F
System Carrying Case
Item No.: 4540011
Bar Code: 4006825653991
Einhell Accessory



E-Case Werkzeugkiste
System Carrying Case
Item No.: 4540037
Bar Code: 4006825677973
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



E-Case Tasche
System Carrying Case
Item No.: 4540036
Bar Code: 4006825677966
Einhell Accessory



E-Case M
System Carrying Case
Item No.: 4540021
Bar Code: 4006825667721
Einhell Accessory

Battery-Running-Times



chiseling¹
(min.)

One Battery for All

1.5 Ah	11
2.0 Ah	15
2.5 Ah	19
3.0 Ah	23
4.0 Ah	30
5.2 Ah	39
6.0 Ah	45
8.0 Ah	60

For best performance select a battery with at least 2.5 Ah

Test setup:

1) brick stone - brick stone - Max. electronic speed