

<div data-bbox="363 181 557 224" data-label="Text"> <h1>HAVIT</h1> </div> <div data-bbox="368 298 602 509" data-label="Image"> </div> <div data-bbox="319 559 602 622" data-label="Caption"> <p>SK800BT PORTABLE WIRELESS SPEAKER PRODUCT MANUAL</p> </div>	<div data-bbox="712 157 823 177" data-label="Section-Header"> <h3>Packing list:</h3> </div> <div data-bbox="721 184 1029 640" data-label="Image"> </div> <div data-bbox="1042 645 1055 659" data-label="Text"> <p>1</p> </div>	<div data-bbox="1123 157 1289 177" data-label="Section-Header"> <h3>Product structure:</h3> </div> <div data-bbox="1198 181 1378 520" data-label="Image"> </div> <div data-bbox="1123 565 1457 631" data-label="List-Group"> <ul style="list-style-type: none"> 1.Multi-function button(MFB) 2.Play/Pause 3.PREVIOUS/VOL- 4.NEXT/VOL+ 5.Micro SD card port 6.Charging port 7.USB port 8.AUX IN </div> <div data-bbox="1455 645 1468 659" data-label="Text"> <p>2</p> </div>	<div data-bbox="1532 146 1659 163" data-label="Section-Header"> <h3>Power ON/OFF</h3> </div> <div data-bbox="1532 163 1853 231" data-label="List-Group"> <ol style="list-style-type: none"> 1.Press and hold the MFB for 3 seconds to turn on, the LED indicator lights up blue for 2s. 2.Press and hold the MFB for 2 seconds to turn off. </div> <div data-bbox="1532 249 1702 266" data-label="Section-Header"> <h3>Wireless connection</h3> </div> <div data-bbox="1532 266 1868 457" data-label="List-Group"> <ol style="list-style-type: none"> 1.Turn on the wireless speaker, the LED indicator flashes blue. 2.Then activate the wireless of your phone and search for "HAVIT SK800BT". Click manually to connect. If the connection is successful, a voice prompt is heard. The blue in dicator lights is on and stop flashes. 3. Since the speaker can automatically reconnect to the last paired device. When the wireless of your device turns on, (Just turn on the speaker), it will automatically reconnect. </div> <div data-bbox="1532 474 1719 491" data-label="Section-Header"> <h3>Answer incoming calls</h3> </div> <div data-bbox="1532 491 1851 526" data-label="Text"> <p>Press the Play/Pause once to answer incoming calls.</p> </div> <div data-bbox="1532 543 1638 560" data-label="Section-Header"> <h3>End the call</h3> </div> <div data-bbox="1532 560 1870 577" data-label="Text"> <p>Press the Play/Pause once to end the current call.</p> </div> <div data-bbox="1532 595 1719 612" data-label="Section-Header"> <h3>Decline incoming calls</h3> </div> <div data-bbox="1532 612 1857 646" data-label="Text"> <p>Long press the Play/Pause for 2s to reject when there comes a call.</p> </div> <div data-bbox="1868 645 1881 659" data-label="Text"> <p>3</p> </div>
<div data-bbox="295 726 610 760" data-label="Text"> <p>LastnumberredialDualshortpresstheplay/pause-button.</p> </div> <div data-bbox="295 777 510 794" data-label="Section-Header"> <h3>One key for voice assistant</h3> </div> <div data-bbox="295 794 587 830" data-label="Text"> <p>Long press the Play/Pause to activate voice assistant.</p> </div> <div data-bbox="295 847 423 863" data-label="Section-Header"> <h3>Mode switching</h3> </div> <div data-bbox="295 863 561 899" data-label="Text"> <p>Short press MFB button to select mode. (Bluetooth /TF card/AUX/USB/FM)</p> </div> <div data-bbox="295 916 412 933" data-label="Section-Header"> <h3>Playing music</h3> </div> <div data-bbox="295 933 591 1021" data-label="List-Group"> <ol style="list-style-type: none"> 1. Short press the Play/Pause to pause/play; 2. Long press the "+" for PREV; 3. Long press the "+" for NEXT. 4. Short press the "+" for VOL -; 5. Short press the "+" for VOL +. </div> <div data-bbox="295 1037 374 1054" data-label="Section-Header"> <h3>FM mode</h3> </div> <div data-bbox="295 1054 629 1193" data-label="List-Group"> <ol style="list-style-type: none"> 1. Insert the provided Type-C cable to the speaker Type-C slot as an antenna. Then turn on the speaker and press MFB once to enter FM mode. 2. Long press the Play/Pause for 2s to activate auto searching for channels. 3. Long press play/pause 2 seconds to stop the search 4. Long press the "+" / "-" to select channel. </div> <div data-bbox="627 1225 642 1239" data-label="Text"> <p>4</p> </div>	<div data-bbox="712 726 800 743" data-label="Section-Header"> <h3>USB mode</h3> </div> <div data-bbox="712 743 1027 779" data-label="Text"> <p>Insert a USB disk, the speaker will automatically broadcasts music in it.</p> </div> <div data-bbox="712 796 872 813" data-label="Section-Header"> <h3>Micro SD card mode</h3> </div> <div data-bbox="712 813 987 865" data-label="Text"> <p>Insert a micro SD card, the speaker will automatically recognize and automatically broadcasts MP3 format music in it.</p> </div> <div data-bbox="712 882 800 899" data-label="Section-Header"> <h3>AUX mode</h3> </div> <div data-bbox="712 899 1040 951" data-label="Text"> <p>Connecting your music player/phone to the speaker via the provided dual 3.5mm audio cable, then the speaker will automatically recognize.</p> </div> <div data-bbox="712 968 1008 1004" data-label="Section-Header"> <h3>True Wireless Stereo (TWS) Fit for two SK800BT speakers</h3> </div> <div data-bbox="712 1004 1049 1039" data-label="Text"> <p>You can connect two SK800BT speakers as a pair for stronger stereo and surrounding effect.</p> </div> <div data-bbox="712 1039 1049 1193" data-label="List-Group"> <ol style="list-style-type: none"> 1. Make sure the Bluetooth function is OFF on your Bluetooth player; 2. Turn on two speakers; 3. Dual press MFB on one of the speakers (and it will be the main speaker) , both of speakers will enter TWS pairing status. Until LED of the main speaker flashes blue and the LED of the auxiliary speaker turns blue, the TWS connection is successful. </div> <div data-bbox="1042 1225 1055 1239" data-label="Text"> <p>5</p> </div>	<div data-bbox="1123 726 1440 779" data-label="List-Group"> <ol style="list-style-type: none"> 4. Then active the Bluetooth of your phone and search for "HAVIT SK800BT". Click manually to connec </div> <div data-bbox="1123 796 1202 813" data-label="Section-Header"> <h3>Charging</h3> </div> <div data-bbox="1123 813 1440 1004" data-label="List-Group"> <ol style="list-style-type: none"> 1. As product has built-in non-removable and rechargeable battery, please use the provided Type-C charging cable to charge. 2. Please choose the charger that is certified by the regular manufacturer. 3. The battery performance may decrease as repeating charging and using the speaker. It's a normal phenomenon for all rechargeable batteries. 4. The power LED lights up red when charging and goes off when charging is complete. </div> <div data-bbox="1123 1021 1238 1037" data-label="Section-Header"> <h3>Specification:</h3> </div> <div data-bbox="1123 1037 1453 1228" data-label="Text"> <p>Wireless version: V5.3 Output power: 4W Battery: 3.7V /900mAh Playing Time: 6H (Medium volume) Talking Time: 6H Charging time: About 4H Supported:BT, AUX, micro SD Card in, FM, TWS, USB, Voice assistant Wireless working range: 10M (without obstacles) Size: 96*68*64mm Material: ABS+Fabric</p> </div> <div data-bbox="1455 1225 1468 1239" data-label="Text"> <p>6</p> </div>	<div data-bbox="1532 726 1625 743" data-label="Section-Header"> <h3>Warnings:</h3> </div> <div data-bbox="1532 743 1876 1125" data-label="List-Group"> <ol style="list-style-type: none"> 1. Please follow the instruction to operate. 2. PLS charge the product with input power below 5V/1A, in order to protect the battery; 3. Please do not use this product in the near water. Do not immerse this product in any liquid or splash any liquid on this product. 4. Please store or use the product in a normal temperature environment. 5. Please keep the product from heat source, such as radiators, hot air regulators, stoves, or other heat generating instruments. As it is not anti-high temperature. 6. Don't jam the ports of the product, such as charger port, LED port and microphone etc.. 7. In order to protect your hearing and extend the speaker service life, it is not recommended to adjust the volume to the maximum level for a long time. 8. Whatever reasons damage the product, please feel free to contact our after-sales staff in time rather than repair by yourself. Otherwise, you will accept without after-sales service. </div> <div data-bbox="1868 1225 1881 1239" data-label="Text"> <p>7</p> </div>