

HATOR® QUASAR 3S ULTIMA 8K


WIRELESS GAMING MOUSE

EN User manual
DE Benutzerhandbuch
FR Manuel utilisateur
IT Manuale d'uso
NL Handleiding
PL Instrukcja obsługi
RO Manual de utilizare
BG Пъководство за употреба
SK Uživatelská príručka

LV Lietotāja rokasgrāmata
LT Vartotojo vadovas
EST Kasutusjuhend
TR Kullanım kılavuzu
JA 取扱説明書
FI Användarmanual
SWE Brukermanual
DAN Brugermanual
AR دليل المستخدم
HE מדריך למשתמש

PACKAGE CONTENT

- Mouse
- Wireless 8K dongle
- 1.5m USB-A to Type-C cable
- Anti-slip mouse grip tape
- Replacement 100% PTFE feet
- Glass feet
- U-PE spot feet
- Mouse bag
- User manual
- Sticker pack



PRODUCT OVERVIEW



1. Left click button
2. Right click button
3. Scroll Wheel/Middle click button
4. Side front mouse button
5. Side back mouse button
6. LED indicator
7. Mode switch
8. DPI change button
9. Sensor lens
10. 100% PTFE feet



IMPORTANT
Charge a mouse from a computer or laptop using a USB cable. Do not use a wall charger with output power more than 10W! It can cause the device to malfunction.

6. LED indicator

RED light charging
Green fully charged
Flashes red when the battery is less than 15%
Shows color of the switched DPI profiles



WIRELESS 8K DONGLE


- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.

8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE


- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.


8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE





- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.

8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE



- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.

8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE







- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.

8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE





- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.

8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE







- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.

8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE







- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.

8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE


- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.

8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE








- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.


8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE






- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.

8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE

- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.


8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE






- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.


8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1000 Purple
1200 Green
1600 Red
3200 Light blue



WIRELESS 8K DONGLE

- Polling rate:**
125Hz
250Hz
500Hz
1000Hz (by default)
2000Hz
4000Hz
8000Hz



IMPORTANT
To prevent interference, we strongly recommend to position a wireless 8K dongle in front of the mouse when connecting to a PC.

8. DPI change button

Use to switch between DPI profiles
Default DPI profiles:
DPI Backlight
400 Yellow
800 Blue (by default)
1

