

SeKi

Easy Plus



Programming



Step 1

Press and hold button "AV", then keep it and press "VOL-" button.

Press both buttons for at least 5 seconds until the corresponding indicator lights up.

The learning system is on now.

Step 2

Hold the sending end of the established remote aiming at the receiving end of Seki Easy Plus. (distance 2-5cm)

Step 3

Press the button of Seki Easy Plus remote control which you want to program.

The indicator will not light.

Step 4

Press the targeted button of the original remote control.

When receiving the correct data, LED will light for 1 second and then flash twice.

Step 5

To learn other buttons repeat steps 3+4 until the end of all learning.

Step 6

When learning is completed, press and release buttons "AV" and "VOL-" at the same time to exit learning state.

You are done and can now use your SeKi Easy Plus.

Copy button for button



www.my-seki.de