

Installation manual

M Collaboration Floorstand 50"-86"

EAN: 7340234814237

(en) Installation manual

(ar) تېبىتال لىلد

(cz) Instalační manuál

(da) Installationsmanual

(de) Installationsanleitung

(ee) Paigaldusjuhend

(el) Οδηγίες εγκατάστασης

(es) Manual de instalación

(fi) Asennusohje

(fr) Installation Manuel

(he) הנקתה יירדמ

(hu) Szerelési kézikönyv

(it) Manuale di installazione

(jp) 取り付け説明書

(kr) 설치 설명서

(li) Montavimo instrukcija

(lt) Uždėdėšanas rokasgrāmata

(nl) Installatie handleiding

(no) Installasjonshåndbok

(pl) Instrukcja instalacji

(pt) Manual de instalação

(ro) Manual de instalare

(ru) Инструкция по установке


(sk) Inštalčný manuál

(sl) Navodila za montažo

(sv) Installationsmanual

(tr) Montaj kılavuzu

(zh) 安装手册



WARNING

WARNING!

Always check the depth of the holes before starting an installation.

ADVARSEL!

Kontroller altid hullernes dybde, før du går i gang med en installation.

WARNUNG!

Vor Beginn des Einbaus immer die Tiefe der Bohrungen überprüfen.

ΠΡΟΕΙΔΟΠΟΙΗΣΗ!

Ελέγχετε πάντα το βάθος των οπών πριν ξεκινήσετε την εγκατάσταση.

¡AVISO!

Controle siempre la profundidad de los agujeros antes de iniciar una instalación.

VAROITUS!

Selvitä reikien syvyyden ennen asentamisen aloittamista.

ATTENTION!

Vérifiez toujours la profondeur des trous avant de commencer une installation.

ATTENZIONE!

Verificare sempre la profondità dei fori prima di iniziare l'installazione.

VAROVÁNÍ!

Před zahájením instalace vždy zkontrolujte hloubku otvorů.

ADVARSEL!

Sjekk alltid hvor dype hullene er før du begynner å montere.

OSTRZEŻENIE!

Przed rozpoczęciem montażu należy zawsze sprawdzić głębokość otworów.

ПРЕДУПРЕЖДЕНИЕ!

Всегда проверяйте глубину отверстий перед началом установки.

WARNING!

Kontrollera alltid hållens djup innan en installation påbörjas.

UYARI!


Kurulumu başlamadan önce daima deliklerin derinliğini kontrol edin.

警告

在安装安装之前, 请务必检查孔的深度。

ريذحت

تېبىتال لىف دېبال لىق بوقىتال قىمىم نىم ئامىد قىقحت.



WARRANTY CARD

www.multibrackets.com

MULTIBRACKETS™ Limited Warranty

Multibrackets warrants its products to be free of defects in material and workmanship for the product's Warranty Period. The Warranty Period commences on the original purchase date of the product.

All Multibrackets products are covered by a limited product warranty:

- Five (5) years for metal video monitor mounts; all racks and non-electrical rack accessories.
- Two (2) years for gaslifts and sit-stand workstations.
- One (1) year for all motorized and/or automated products, plastic speaker mounts; all speaker stands; all furniture; all wood (MDF) accessories.

For warranty claims made during the Warranty Period, MULTIBRACKETS™ will replace any defective product part free of charge. Should a part on your Multibrackets product fail, please create an RMA case on www.multibrackets.com/support to make a warranty claim. We will await your documentation and then discuss the problem with you and once we confirm the product is under warranty, we will ship replacement parts to you. This Limited Warranty does not cover the costs of removing and replacing defective parts from your Multibrackets product. So, if your problem requires a repair technician, you must pay any labor charges.

This Limited Warranty extends only to the original purchaser of the product and is automatically void if your Multibrackets product is modified in anyway, improperly installed, taxed beyond its stated weight capacity or otherwise misused or abused.

All Multibrackets products are intended for indoor use only and any outdoor use voids this Limited Warranty. The Limited Warranty for wall and ceiling mounts is void if the mount is moved from its initial installation. To the maximum extent permitted by applicable law, Multibrackets disclaims any other warranties, express or implied, including warranties of fitness for a particular purpose and warranties of merchantability. Multibrackets will not be liable for any damages whatsoever arising out of the use or inability to use its products, even if Multibrackets has been advised of the possibility of such damages. To the maximum extent permitted by applicable law, Multibrackets disclaims any responsibility for incidental or consequential damages.



Multibrackets™ Stockholm, Sweden 2026
www.multibrackets.com



Multibrackets Online Users Manual

The content of this manual is subject to change without further notice.

The latest version of this manual can be found online under the product name on the website: www.multibrackets.com



CAUTION

Two persons recommended to install this product



Multibrackets® Europe AB
Sveavägen 140, SE-113 50 Stockholm, Sweden.

www.multibrackets.com

Contents

Contents	04
CAUTION	05
Part list and Hardware kit	06
1.Technical specification	07
2.Caster installation	08
3.Leg and upright assembly.....	09
4.Height adjustment	10
5.Tray and crossbar assembly	11
6.Pillars and crossbar assembly.....	12
7.VESA mounting frame assembly	13
8.VESA mounting patterns	14
9.VESA rails and screen assembly.....	15
10.Mounting the screen on the cart.....	16
11.Cable management.....	17











CAUTION

Important safety instructions & assembly guide

- Please read and understand all instructions and safety information provided before starting the installation process. Improper installation or assembly may result in personal injury or property damage.
- This product is compatible with most 50"-86" TVs. The maximum load capacity is 90 kg, and the maximum AV shelf load capacity is 4.5 kg. Overloading the product may cause instability and result in potential personal injury.
- Do not install or assemble if any part of the product or hardware is damaged or missing. For replacement parts, please contact your local distributor. If you have any questions or concerns regarding the instructions, please consult a qualified local installer.
- This product is designed for indoor use only. Securely tighten all assembly screws, but avoid over-tightening. We disclaim all liability for damages or injuries resulting from modifications, improper installation, incorrect assembly, or inappropriate use.
- Properly assemble the VESA rails vertically on the back of the TV and align the TV to the central position for optimal stability.
- Install and use the product only on a flat, solid, and level surface to prevent tipping. Lock the casters to secure the unit in place and unlock them when 360-degree mobility is required.
- This product contains moving parts and small components. Keep children away from the product to avoid tipping hazards or risk of choking. Using a tip-over restraint or anchoring the stand to the wall may reduce, but not eliminate, the risk of tipping. Continuous adult supervision is necessary.
- Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing, and as a result, the furnishing may tip over onto the child.
- Relocating audio and/or video equipment to furniture not specifically designed to support audio and/or video equipment may result in death or serious injury due to the furnishing collapsing or overturning onto a child.

Parts

1 A  1X	2 B  1X	3 C  4X	4 D  1X
5 E  1X	6 F  1X	7 G  1X	8 H  1X
9 J  4X	10 K  4X	11 L  2X	12 M  3X

Hardware kit





<p>a</p>  <p>M8x60mm 8x</p>	<p>b</p>  <p>M6x10.5mm 8x</p>	<p>c</p>  <p>Ø8.2x1.2mm 8x</p>	<p>d</p>  <p>5mm 1x</p>	<p>Screws for cart assembly color : black</p>	
<p>e</p>  <p>M5x10mm 6x</p>	<p>f</p>  <p>M6x20mm 2x</p>	<p>g</p>  <p>lock ring 1x</p>			

<p>g</p>  <p>M10x15mm 4x</p>	<p>h</p>  <p>M8x25mm 4x</p>	<p>i</p>  <p>M6x25mm 4x</p>	<p>j</p>  <p>M5x25mm 4x</p>	<p>k</p>  <p>Ø6.2mm x1.5mm 4x</p>	<p>l</p>  <p>Ø8.2mm x10mm 4x</p>	<p>Screws for screen assembly color : silver</p>
---	--	--	--	--	---	--

Manual


							
Tightening	Loosening	Philips Screwdriver	Tape Measure	Adjustment	By Hand	Hex Wrench	+ Tightening - Loosening

1. Technical specification




2. Caster installation


Step 1: Brake the casters before assembly.



Step 2: Put the lock ring (g) on the thread of one caster (J), then assemble it onto the leg (C).




Step 3: Assemble the other three caster (J) onto the leg (C)




3. Leg and upright assembly

Step 1: Insert the top end of the leg into the bottom of the upright (A&B)




Step 2: Secure the leg and uprights together with screw (b) by Allen key (d)



4. Height adjustment

1st hook



Note:

Height is set at initial position.
Please adjust to desired height for your use

Note:

Heights in diagram indicate the distance from floor to the center of TV, when VESA on TV is in center, otherwise, height for reference only.

Important:


Left and right pillars must be set at the same height.

Step 1: Take out the screw with Allen key (d)

Step 2: Adjust the pillars to the desired height, and then fix the height with the screw, which is taken out in step 1, by Allen key (d)

Important:



Ensure the screws are secured firmly after height is set.




5. Tray and crossbar assembly

Assemble crossbar (D) and tray (F) together with screw (e),
grooving side facing up

e. 1:1 diagram




6. Pillars and crossbar assembly





Note:
Ensure screws are secured firmly.

Important:
At least two persons are required
for assembly.

a. 1:1 diagram




c. 1:1 diagram




7. VESA mounting frame assembly


Note:
Assemble the frame as per label instructions





c. 1:1 diagram



a. 1:1 diagram








Note:
Ensure screws are secured firmly.




8. VESA mounting patterns

VESA: 200x200~800x600mm




9. VESA rails and screen assembly





Note:
Based on the screw specifications,
choose one of the following three installation methods




① M10×15mm(g)



② M8×25mm(h)+I






③ M5×25mm(j)
M6×25mm(i) +k+l



Note:
Please use spacers to fix screws onto TV,
lest damage to TV due to overlong screws

10. Mounting the screen on the cart




Caution:

To prevent TV from colliding with the bracket, please adjust the bracket to the proper height before hanging on TV.

Note:

If VESA holes on TV are on the upper position, it is suggested to use the second hooker on VESA rails to hang on the TV

Move TV to the center position



Important:


Move TV to the center position.

Warning:


At least two persons are required to mount TV. Holding TV firmly by the bottom to avoid possible damage due to slide-off

Warning:

To avoid property damage and personal injury, please ensure clips are secured firmly.



f. 1:1 diagram



11. Cable management

