




IB-WL101

Wireless Transmitter and Receiver USB Type-C® to HDMI®
Drahtloser Sender und Empfänger USB Typ C® zu HDMI®
Émetteur et récepteur sans fil USB Type-C® vers HDMI®
Bezprzewodowy nadajnik i odbiornik USB typu C® do HDMI®





1x




1x



1x




Legacy USB standards	Current USB standards	Data transfer rate
USB 3.0 = USB 3.1 (Gen 1)	= USB 3.2 Gen 1	= 5 Gbit/s
USB 3.1 = USB 3.1 (Gen 2)	= USB 3.2 Gen 2	= 10 Gbit/s
USB 3.2 (Gen 2x2)	= USB 3.2 Gen 2x2	= 20 Gbit/s
	= USB4® Gen 2x1	= 10 Gbit/s
	= USB4® Gen 2x2	= 20 Gbit/s
	= USB4® Gen 3x2	= 40 Gbit/s



www.icybox.de

BACK



© Copyright 2026 by RaidSonic Technology GmbH.
All Rights Reserved.


The information contained in this manual is believed to be accurate and reliable. RaidSonic Technology GmbH assumes no responsibility for any errors contained in this manual. RaidSonic Technology GmbH reserves the right to make changes in the specifications and/or design of the above-mentioned product without prior notice. The diagrams contained in this manual may also not fully represent the product that you are using and are there for illustration purposes only. RaidSonic Technology GmbH assumes no responsibility for any differences between the product mentioned in this manual and the product you may have. Apple and macOS are registered trademarks of Apple Computer Inc. Microsoft, Windows and the Windows logo are registered trademarks of Microsoft Corporation. USB Type-C and USB-C are registered trademarks of USB Implementers Forum. The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Version 1.26




1

A




B



Power adapter not included
Netzteil nicht im Lieferumfang enthalten
Adaptateur secteur non inclus
Zasilacz nie jest dołączony

2



press the reset button for 2 seconds to turn on pairing mode
press the reset button for 10 seconds to reset to factory settings




Drücken Sie die Reset-Taste 2 Sekunden lang, um den Pairing-Modus zu aktivieren.
Drücken Sie die Reset-Taste 10 Sekunden lang, um die Werkseinstellungen wiederherzustellen.

appuyez sur le bouton de réinitialisation pendant 2 secondes pour activer le mode d'appairage
appuyez sur le bouton de réinitialisation pendant 10 secondes pour rétablir les paramètres d'usine


naciśnij przycisk resetowania przez 2 sekundy, aby włączyć tryb parowania
naciśnij przycisk resetowania przez 10 sekund, aby przywrócić ustawienia fabryczne



1



2



3

