



Manual

GD-25LK01

CE

1	General information	3
1.1	Introduction	3
1.2	Scope of delivery	3
2	Safety.....	4
2.1	Intended use	4
2.1.1	Application area and local requirements	4
2.1.2	Disposal.....	4
2.2	General notice	4
2.3	Danger and protection.....	4
3	Product information	5
3.1	Features.....	5
3.2	Technical Specification.....	5
4	Installation and use	6
4.1	Mounting of HDD.....	6
4.2	Hardware Setup	7
4.2.1	LED display	7
4.2.2	Password Setup	8
4.2.3	Change of Password	8
5	Handling	9
5.1	Use of device	9
5.2	Locking of device	9
5.3	Unlocking of device	9
6	FAQ.....	10
7	Maintenance.....	11
8	Disposal	11
9	Warranty terms	12
10	Contact	13



1 General Information

1.1 Introduction

Thank you for buying an enclosure of our Argus-series.

This USB 3.0 hard disk enclosure will protect your data for unauthorized access by password setting.

The enclosures of the Argus-series comply to RoHS II.

We recommend to read this manual before installing or using this device.

1.2 Scope of delivery

1x Hard disk enclosure

1x USB 3.0 Cable



2 Safety

2.1 Intended use

2.1.1 Application area and local requirements

This product is only for use in combination with computers inside of rooms.

Don't use or store this product close to water or in humid rooms.

Don't use this product close to heat. The additional heat could cause overheating or fire.

2.1.2 Disposal

Don't put this product to the general trash

This product can be disposed at the intended places without any costs.



2.2 Generelle Hinweise

Please read this manual before installing or using.

Please keep this manual and pass it if the product will be passed.

Please follow the introductions and warnings.

The non-observance of this manual can cause defects, violation or death.

We assume no liability for damages or violations caused by the non-observance of this manual.

2.3 Danger and protection

Don't place the product close to heatings.

Don't operate the products with wet or humid hands.

Don't pull out the power supply by pulling the cable.

Don't use repaired or defective cables.

In case of strange noise or smell, pull out the power supply immediately.

Don't open the product or the power supply.

Please take care that all cables will be connected stable.

Take electric products away from children.

Don't pull out the power supply with wet or humid hands.

Pull out the power supply from socket in case of longer non-use.

Maintenance and cleaning only by authorized personnel.



3 Product information

3.1 Features

- Data protection by AES 256-bit Hardware encoding
- SuperSpeed USB 3.0 connection
- Build-In Keypad
- Screwless hard disk mounting

3.2 Technical specifications

Connection	USB 3.0 (5 Gbps), USB 2.0 (480Mbps)
Hard disks	Supports 2,5" SATA I, II, III (Up to 9,5mm height)
LEDs	Power/ HDD activity/ Encoding status
Power Supply	by USB 5V
Operation temperature	5 °C to 50 °C
Storage temperature	-40 °C to 70 °C
Humidity	5% to 90%, non condensed
Supported OS	Windows 200/ XP/ Vista/ 7/ 8 Mac OS up from Version 9.1 Linux 2.4.2
Dimension	123,6 x 76,1 x 17,6mm

4 Installation and use

4.1 Mounting of HDD

1. Unpack the device and control for defects and missing parts of scope of delivery.

In case of missing parts or defects contact your local dealer please.

Keep the original package in case of RMA.

2. The enclosure must not be connected to your computer during mounting the HDD.


3. **Please note that all data on HDD will be deleted during first installation. Please use an empty HDD or save your data first.**

Up from first installation your data are only accessible by using a GD-25LK01 enclosure.


In case of a faulty enclosure the hard disk have to be mounted in another GD-25LK01 to get access to the data.

In case of password loss is no further access possible. Please write down your password somewhere.


4. Push the cover in direction of arrow.




5. Take off the cover



6. Slide the harddisk carefully into the slot.




7. Close the enclosure



4.2 Hardware Setup

4.2.1 LED displays

Blue LED	Lighted during operation Flashing during data transfer
Green LED	Lighted if enclosure is unlocked Flashing once for input confirmation
Orange LED	Lighted for password setting or change mode
Red LED	Lighted if enclosure is locked Flashing if password input is faulty





4.2.2 Password Setup

Please note that all data on your hard disk will be deleted during first configuration. Please take an empty hard disk or save your data before first configuration.

1. Push the buttons „1“ and „3“ at once and connect the enclosure with your computer. Wait till RED and BLUE LED are lighted and loose both buttons.
2. Push the “lock” button (The button with the closed lock) for 10 sec. till the ORANGE LED is lighted.
3. Insert the password. The password must have between 1 to 12 digits.

Choose an, for you, easy to remember password or write down the password.

There will never be any access to your data without your chosen password.

Finish the input by pushing the „Unlock“ button (The button with the open lock).

4. Type your password again and confirm it by pushing the „Unlock“ button.

Now the RED LED will go off and the GREEN LED will light.

The password configuration is finished.

5. Now partition and format your hard disk by using your OS.

In case you don't know how to do, please ask an expert for help. Wrong formatting or partitioning can delete data on your computer.

4.2.3 Change the password

1. Disconnect the enclosure from computer
2. Push the „Lock“ button and connect the enclosure with the computer.
3. Hold it for 10 sec till the RED and ORANGE LED will light.
4. Enter the old password and confirm it by pushing the “Unlock” button.
5. Enter the new password and confirm it by pushing the “Unlock” button.
6. Repeat step 5
7. Now the RED LED will go off and the GREEN LED will light. The password is changed successfully.



5 Handling

5.1 Use of device

You can always get access to your device by entering the password and confirmation by pushing the „Unlock“ button. The GREEN LED will show the state of readiness.

5.2 Locking the device

1. The device will be locked automatically by disconnecting from computer.
2. The device will be locked automatically in case of no HDD activity for more than 10 minutes.
3. You can lock the device every time by pushing the „Lock“ button.

5.3 Unlocking the device

After all above described locks you unlock the device by entering your password and pushing the „Unlock“ button.



6 FAQ

In case of forgotten password

If you have forgotten your password neither you or our service can get access to your data. So, please write down your password and store it at a safety place.

What if the enclosure is defective?

You have to mount your hard disk to another GD-25LK01 to get access to your data. Your old password will be kept automatically.

Repeated faulty input

There's no restriction of the quantity for wrong inputs.

What will happen if the change of the password will be failed?

You just have to enter the last valid password to get access.

What will happen if the connected and unlocked enclosure will be unused for longer time?

The enclosure will lock automatically after 10 min.

Can I get access to my data by mounting the hard disk in another „normal“ enclosure?

No, in case of changing to another normal enclosure you will have no access to your data.

Can I encrypt a hard disk when it's already written?

No. A later encryption is not possible. In this case all data on the hard disk will be deleted.

Can I use different hard disks with one enclosure?

Yes, you can switch between different hard disks. But you will get access to your data only in combination with that enclosure.

7 Maintenance

This product needs no maintenance.

8 Disposal

Please dispose your product by using the special discharge point for electronic waste. Please ask your municipality or disposal company in case of further questions.



9 Warranty terms

Inter-Tech grants 24 months warranty by proper use up from the date of purchase.

In case of warranty please contact your local dealer or the dealer from which you bought the product.

We will grant no warranty by:

- Missing or damaged warranty seal,
- Negligent behavior,
- Improper use,
- Nonobservance of the manual,
- External violence,
- Acts of god,
- Damages caused by manipulation, upgrading, updating or reconstruction of hardware or software
- Damages caused by other harm,

In case of data loss Inter-Tech will only be liable at wanton negligence or deliberate intention or, in all other cases, only for the recovery of data from a continuous, daily backup. Inter-Tech does not assume liability for all other matters.

Please look also at our complete warranty terms on our website.



10 Contact

Inter-Tech Elektronik Handels GmbH
Hainhäuser Weg 93
D-30855 Langenhagen
Germany

Tel: +49 511 72667830
Fax: +49 511 72667837
Email: vertrieb@inter-tech.de

Web: www.inter-tech.de
www.sinan-power.de
www.cobanitrox.de

This product complies to the directives 2004/108/EG and 2011/65/EG of the council of the European Parliament and the Council of the European Union.

The declaration of conformity will be shown on our website:

[Service & Support/ Downloads/ Declarations](#)

