



Einhell

EXPERT



Cordless Mitre Saw

TE-MS 18/210 Li - Solo

Item No.: 4300890

Ident No.: 11017

Bar Code: 4006825628074

Features & Benefits

- Member of the Power X-Change family
- Boundless reach of action, no annoying cable, nothing to wind
- Compact, light construction and handle for easy transportation
- Turntable with precise angle setting for angular cuts
- Saw head tilts to the left and right for miter cutting
- X-Tend work supports with ergonomic singlehand operation facility
- High-grade precision saw blade, developed for cordless mitre saws
- Laser and LED for easy and safe use
- Clamping device for holding the workpiece securely in position
- Includes sawdust bag to keep the workplace clean
- Recommendation for best results: 2.6 Ah Plus battery or higher




Technical Data

- | | |
|--------------------------------|------------------------|
| - No-load speed (idle speed) | 3000 min ⁻¹ |
| - Saw blade | Ø210 x Ø30 mm |
| - Number of teeth | 40 Pieces |
| - Mitre cut | 45 ° - 0 ° |
| - Swivelling range | 47 ° - 47 ° |
| - Cutting capacity 90° x 90° | 120 x 60 mm |
| - Cutting capacity 90° x 45° | 83 x 60 mm |
| - Cutting capacity 45° x 90° | 120 x 34 mm |
| - Cutting capacity 45° x 45° | 80 x 34 mm |
| - Diameter of suction adapter | 36 mm |



Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight (kg) | 7 |
| - Gross weight (kg) | 9.23 |
| - Dimensions single packaging | 540 x 355 x 300 mm |
| - Pieces per export carton | 1 Pieces |
| - Gross weight of export carton | 9.9 kg |
| - Dimensions export carton | 540 x 380 x 340 mm |
| - Container quantity (20"/40"/40"HC) | 384 780 1040 |



Available as special accessories



18V 1,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512021
Bar Code: 4006825601350
Einhell Accessory



18V 2,0 Ah Power-X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 30min Power-X-Change
PXC-Charger
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory



18V 3,0 Ah Power-X-Change
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 2,6Ah P-X-C Plus
Battery
Item No.: 4511436
Bar Code: 4006825616590
Einhell Accessory



18V 5,2 Ah P-X-C Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory