

Product data sheet



Symbols for CD 500, WG 600, AP 600



Reference number

33 L WW

Symbols

for switches and push-buttons with indicator light in design range WG 600
for switches and push-buttons with indicator light ref.-no.: 602 KOA .., 631 A .., 634 A ..,
633 A ..
for push-buttons ref.-no.: 331 A, 333 A

Colour:
white

Version:
symbol light