

CNS 18-30 BATTERY

Simple to use, versatile and perfect for tree maintenance: the lightweight CNS 18-30 Battery chain saw with tool-less chain tensioning system.



Order no. 1.444-001.0

- Ideal for tree maintenance where the branches are thin
- User-friendly settings and operation
- Chain brake and safety unlocking for safe use

Technical data

EAN code		4054278548937
Battery powered device		1
Battery platform		18 V battery platform
Guide rail	cm	30
Chain speed	m/s	10
Chain pitch		3/8" LP
Chain gauge		1.1 mm / 0.043"
Number of drive links		45
Oil tank capacity	ml	200
Guaranteed sound power level	dB(A)	101
Vibration value of front handle ($\Delta K=1.5 \text{ m/s}^2$)	m/s^2	3.5
Vibration values for rear handle ($\Delta K=1.5 \text{ m/s}^2$)	m/s^2	5.2
Drive		Brushless motor
Voltage	V	18
Performance per battery charge *	Cuts	max. 35 (2.5 Ah) / max. 70 (5.0 Ah)
Runtime per battery charging	min	max. 10 (2.5 Ah) / max. 20 (5.0 Ah)
Colour		Yellow
Weight without accessories	kg	3.4
Weight incl. packaging	kg	5.6
Dimensions (L x W x H)	mm	690 x 230 x 245

Equipment

Variant	Battery and charger not included
Guide rail	■
Saw chain	■
Oil bottle	■
chain protection	■
Tool-less chain tensioning	■
Automatic chain lubrication	■
Chain brake	■
Oil level indicator	■

■ Included in the scope of supply.

* Ø branches: 10 cm



Tool-less chain tensioning

- The chain is simply tensioned using a knob.



Automatic chain lubrication

- For low-maintenance use of the battery chain saw.




Kickback protection

- The chain stops immediately – for maximum safety in the event of a recoil effect.

ACCESSORIES FOR CNS 18-30 BATTERY

1.444-001.0



		Order no.	Description	
BATTERIES				
Battery Power 18/50	1	2.445-035.0	18 V / 5.0 Ah Kärcher Battery Power exchangeable battery with innovative Real Time Technology incl. LCD display to indicate battery level. Suitable for use in all devices on the 18 V Kärcher battery platform.	☐
BATTERY CHARGERS				
Fast Charger Battery Power 18 V	2	2.445-032.0	The fast charger charges the 18 V/2.5 Ah Kärcher Battery Power exchangeable battery to 80% in just 44 minutes and can be used for all batteries on the 18 V Kärcher battery platform.	☐
STARTERKIT BATTERIES AND BATTERY CHARGERS				
Starter kit Battery Power 18/50	3	2.445-063.0	Incl. 18 V / 5.0 Ah Kärcher Battery Power exchangeable battery and 18 V fast charger: The Battery Power 18/50 Starter Kit for use in all devices on the Kärcher 18 V battery platform.	☐
CHAINSAW				
CNS 18-30 Battery chain	4	2.444-019.0	Achieve highest quality cuts every time with the CNS 18-30 Battery chainsaw's chain on its 30 cm long bar. Replacement is effortless thanks to the tool-less chain tensioning system.	☐
CNS 18-30 guide rail	5	6.444-266.0	Perfectly compatible with the CNS 18-30 battery chain saw from Kärcher: The guide rail is ultra-simple to change and helps deliver the best possible cutting results.	☐
BATTERIES				
Battery Power+ 18/30	6	2.445-042.0	With Real Time Technology displayed on an LCD screen: very powerful Battery Power+ 18-volt lithium-ion battery. Long runtime thanks to a capacity of 3.0 Ah. With voltage monitoring and IPX5 protection.	☐

■ Included in the scope of supply. ☐ Available accessories. ☐ Detergents.