

UGREEN

USB-C SD/TF CARD READER

MANUAL

Model:CM184 | P/N:50704

English

Thank you for purchasing the UGREEN products. For optimum operation, please read this manual carefully before use.

PRODUCT DETAILS

1. USB-C Plug
2. SD Card Slot
3. TF Card Slot

— 1 —

HOW IT WORKS

SD Card
UGREEN
TF Card

Note:
Always use the Safely Remove Hardware feature before disconnecting your memory card.

— 2 —

Deutsch

Vielen Dank für den Einkauf von UGREEN Produkten. Für eine optimale Bedienung lesen Sie bitte diese Bedienungsanleitung sorgfältig durch.

PRODUKTDDETAILS

1. USB-C Stecker
2. SD Kartenschlitz
3. TF Kartenschlitz

— 3 —

WIE ES FUNKTIONIERT

SD Card
UGREEN
TF Card

Hinweis:
Verwenden Sie immer die Funktion Hardware sicher entfernen, bevor Sie die Speicherkarte entfernen.

— 4 —

Français

Merci d'avoir acheté le produit d'UGREEN. Afin de garantir le fonctionnement optimal, veuillez lire attentivement ce manuel avant l'utilisation.

DÉTAILS DU PRODUIT

1. Connecteur USB-C
2. Slot de Carte SD
3. Slot de Carte TF

— 5 —

FONCTIONNEMENT

SD Card
UGREEN
TF Card

Note:
Veuillez Retirer le Périphérique en Toute Sécurité avant de déconnecter votre carte mémoire.

— 6 —

Español

Gracias por comprar UGREEN producto. Para obtener los óptimos rendimientos, haga el favor de leer detenidamente este manual antes de usarlo.

DETALLES DE PRODUCTO

1. Conector USB-C
2. Ranura para Tarjeta SD
3. Ranura para Tarjeta TF

— 7 —

CÓMO FUNCIONA

SD Card
UGREEN
TF Card

Note:
Siempre es recomendable usar el icono de "quitar hardware de forma segura" antes de retirar la tarjeta de memoria.

— 8 —

Italiano

Grazie per acquistare i prodotti UGREEN. Per operazione ottimale, si prega di leggere attentamente questo manuale prima di utilizzare.

DETTAGLI DEL PRODOTTO

1. Connettore USB-C
2. Slot per Scheda SD
3. Slot per Scheda TF

— 9 —

COME FUNZIONA

SD Card
UGREEN
TF Card

Nota:
Utilizzare sempre la funzionalità Rimozione Sicura dell'Hardware prima di scollegare la scheda di memoria.

— 10 —

日本語

この度はUGREEN製品をお買い上げいただき、誠にありがとうございます。製品を正しく安全にご使用いただくために、ご使用前にこのマニュアルをよくお読みください。そのあとは是非大切に保管してください。

商品仕様

1. USB-Cプラグ
2. SDカードスロット
3. TFカードスロット

— 11 —

使用方法

スマホ
PC
SDカード
UGREEN
TFカード

ご注意：
メモ리카ードを取り外す前に、必ずハードウェアの安全な取り外し機能をご利用ください。

— 12 —

简体中文

尊敬的用户，感谢您选购绿联产品。为了能进一步了解产品，使用前请仔细阅读本说明书。祝您体验愉快！

产品示意图

1. USB-C
2. SD卡槽
3. TF卡槽

— 13 —

连接示意图

手机
电脑
SD卡
UGREEN
TF卡

注意：
请先在电脑上安全移除操作再拔出TF/SD存储卡。切勿强行拔出，以免造成资料或者磁盘错误、损坏或丢失。

— 14 —

IMPORTANT WEEE INFORMATION

This symbol on the product(s) and / or accompanying documents indicates that, under the new Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), product(s) used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge.

Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling.

Please contact your local authority for further details of your nearest designated collection point.

Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.

For professional users in the European Union
If you wish to discard electrical and electronic equipment (EEE), please contact your dealer or supplier for further information.

For disposal in countries outside of the European Union
This symbol is only valid in the European Union (EU). If you wish to discard this product please contact your local authorities or dealer and ask for the correct method of disposal.

WARRANTY INFORMATION

A limited 2-year warranty applies to all UGREEN products purchased from UGREEN official store or authorized sellers. Please feel free to contact us if you run into any problems.

CONTACT US

FOR AMAZON MARKETPLACES

NORTH AMERICA

US: support.us@ugreen.com
MX: support.mx@ugreen.com

CA: support.ca@ugreen.com

EUROPE

UK: support.uk@ugreen.com
FR: support.fr@ugreen.com
IT: support.it@ugreen.com

DE: support.de@ugreen.com
ES: support.es@ugreen.com

ASIA PACIFIC

JP: support.jp@ugreen.com

AU: support.au@ugreen.com

MIDDLE EAST

UAE: support-uae@ugreen.com

KSA: support-ksa@ugreen.com

MORE SALES CHANNELS

ALIEXPRESS: aliexpress.support@ugreen.com
LAZADA: lazada.support@ugreen.com
EBAY: ebay.support@ugreen.com
SHOPEE: shopee.support@ugreen.com
WHOLESALE BUSINESS: partner@ugreen.com

FCC STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Learn more about the EU Declaration of Conformity:
<https://www.ugreen.com/download/>

UGREEN GROUP LIMITED

www.ugreen.com

support@ugreen.com

+86-755-28066530

@ugreen.fans

@ugreen_official

@Ugreen_Official

Ugreen Building, Longcheng Industrial Park,
Longguanxi Road, Longhua, Shenzhen, China

UGREEN is a registered trademark of Ugreen Group Limited.
All rights reserved.