

CONNECTORS

5 Volt Connector:

**ATTENTION!!!****Use only with included power supply!!!**

HARDWARE INSTALLATION

Because there are large differences between PC's and network's, we can give you only a general installation guide for the EX-1444. Please refer your computer's reference manual or contact your network admin whenever in doubt.

1. At first connect the Transmitter via the included USB cable to the USB port on your PC.
2. Now connect the included power supply (**5V / 0.85A**) to the 5V connector of the Transmitter.
3. Connect a RJ45 patch cable (optional) to the RJ45 port of the Transmitter and connect the other and of the network cable to the RJ45 port of the Receiver.
4. Now connect the included power supply (**5V / 2A**) to the 5V connector of the Receiver.

Attention! Please ensure that the correct power supplies are connected, otherwise the Transmitter and Receiver are not recognized

DRIVER INSTALLATION

All OS

After the hardware installation the OS will recognize the device automatically and install the drivers.

CHECK INSTALLED DRIVER

Open the **>Device manager<**. Now you should see at „**USB-Controller**“ the following new entries: **<Generic USB Hub>**.


If you see this or a similar information the device is installed correctly.

CLEANING

For cleaning please use only a dry fluff less cloth and remove the dirt with gently pressure. In the area of the connectors please make sure that no fibres from the cloth remain in the connectors. **Attention! Never use a moist or wet cloth for cleaning!**



AUFBAU



BESCHREIBUNG & TECHNISCHE DATEN

Die EX-1444 besteht aus einem Transmitter und Receiver. Der Transmitter ist mit einer USB B-Buchse zum Anschluss an den PC, mit einem RJ45 Anschluss und einer 5V Buchse ausgestattet. Der Receiver ist mit vier USB 2.0 A-Buchsen für Endgeräte, einem RJ45 Anschluss und einer 5V Buchse ausgestattet. Die EX-1444 ermöglicht Ihnen auf einfachste Weise, externe USB Festplatten, USB Sticks, USB Scanner, Drucker, Tastaturen etc. über ein Netzkabel anzuschließen. Sie können 4 USB Geräte an die EX-1444 anschließen. Sie ermöglicht Ihnen somit eine erweiterte Flexibilität und Reichweite zum Anschluss der USB Geräte. Durch die externe Stromversorgung der Netzteile wird der Transmitter und Receiver funktionsfähig und es werden an den USB Ports die vollen 500mA zur Verfügung gestellt. Die Datenübertragungsrate beträgt bis zu 480Mbit/s. Die EX-1444 ist Plug and Play fähig. Es wird keine Software oder Treiber benötigt.

Kompatibilität: USB 1.1, 2.0 & 3.0 Anschluss
Betriebssysteme: Alle Betriebssysteme
Anschlüsse: 4x USB 2.0 A-Buchse, 1x USB 2.0 B-Buchse, 2x RJ45 Ethernet, 2x 5V Buchse
Lieferumfang: EX-1444, Anleitung, Netzteile, Schrauben
Zertifikate: CE / FCC / RoHS / WEEE DE97424562

ANSCHLÜSSE

USB 2.0 A-Buchse:



USB 2.0 A-Buchse			
Pin	Signal	Pin	Signal
1	VCC	3	DATA+
2	DATA-	4	GND

Achtung!
Stecker nie umgekehrt oder mit Gewalt einstecken.

USB 2.0 B-Buchse:



USB 2.0 B-Buchse			
Pin	Signal	Pin	Signal
1	VCC	3	DATA+
2	DATA-	4	GND

Achtung!
Stecker nie umgekehrt oder mit Gewalt einstecken.

RJ45 Anschluss:



RJ45 Anschluss					
Pin	Signal	Pin	Signal	Pin	Signal
1	BI_DA+	4	BI_DC+	7	BI_DD+
2	BI_DA-	5	BI_DC-	8	BI_DD-
3	BI_DB+	6	BI_DB-		

ANSCHLÜSSE

5 Volt Buchse:



ACHTUNG!!!

Nur zur Verwendung mit im Lieferumfang enthaltenem Netzteil!!!!

HARDWARE INSTALLATION

Beachten Sie bitte die folgenden Installationshinweise. Da es große Unterschiede zwischen PC's und Netzwerken gibt, können wir Ihnen nur eine generelle Anleitung zum Anschluss geben. Bei Unklarheiten halten Sie sich bitte an die Bedienungsanleitung Ihres Computersystems oder wenden Sie sich bitte an Ihren Netzwerkadministrator.

1. Verbinden Sie zuerst den Transmitter über das mitgelieferte USB Kabel mit einem USB Port Ihres PC's.
2. Jetzt schließen Sie das mitgelieferte Netzteil (**5V / 0.85A**) an die 5V Buchse des Transmitters an.
3. Schließen Sie jetzt ein Netzkabel (optional) an den RJ45 Anschluss des Transmitter an und verbinden Sie das andere Ende des Netzkabel mit dem RJ45 Anschluss des Receiver.
4. Nun schließen Sie das mitgelieferte Netzteil (**5V / 2A**) an die 5V Buchse des Receiver an.

Wichtig! Bitte achten Sie darauf, dass die richtigen Netzteile angeschlossen sind, da ansonsten der Transmitter und Receiver nicht erkannt werden.

TREIBER INSTALLATION

Alle Betriebssysteme

Nach Abschluss der Hardwareinstallation erkennt das Betriebssystem die EX-1444 automatisch und installiert diesen.


ÜBERPRÜFEN DES INSTALLIERTEN TREIBER

Öffnen Sie den **>Geräte-Manager<**. Jetzt müssten Sie unter „**USB Geräte**“ folgende Einträge sehen: **<Generic USB Hub>**.


Sind diese oder ähnliche Einträge vorhanden, ist die EX-1444 richtig installiert.

REINIGUNG

Zur Reinigung des Gerätes verwenden Sie bitte ausschließlich ein trockenes nicht faserndes Tuch und entfernen Sie die Verschmutzung mit leichtem Druck. Im Bereich der Anschlüsse bitte darauf Achten, dass keine Fasern des Tuchs in der Buchse hinterlassen werden. **Verwenden Sie bitte zu Reinigung in keinem Fall ein feuchtes oder nasses Tuch!**



LAYOUT



DESCRIPTION & TECHNICAL INFORMATION

The EX-1444 consists of a Transmitter and Receiver. The Transmitter is equipped with a USB B-Port for connection to the PC, one RJ45 Port and one 5V connector. The Receiver provide four USB 2.0 A-Ports for devices, one RJ45 Port and one 5V connector. The EX-1444 is designed to connect your USB devices such as a external Hard drive, Flash Memory, USB Scanners, USB Printers etc. via a network cable. It delivers simple, reliable and cost effective network connectivity for USB devices. You can connect four USB device to the EX-1444. Via the external power supplys the Transmitter and Receiver is functional and it provides a maximum of power on all four USB ports of 500mA. It uses data transfer rates up to 480Mbit/s. The EX-1444 is Plug and Play compatible. It will not require any software or drivers.

Compatibility: USB 1.1, 2.0 & 3.0
Operating system: All OS
Connectors: 4x USB 2.0 A-Port, 1x USB 2.0 B-Port, 2x RJ45 Ethernet, 2x 5V Connector

Extent of delivery: **EX-1444, Manual, Power Supplys, Screws**

Certificates: **CE / FCC / RoHS / WEEE** DE97424562

CONNECTORS

USB 2.0 A-Port:



USB 2.0 A-Port			
Pin	Signal	Pin	Signal
1	VCC	3	DATA+
2	DATA-	4	GND

Attention!
Never plug in with force or in wrong direction.

USB 2.0 B-Port:



USB 2.0 B-Port			
Pin	Signal	Pin	Signal
1	VCC	3	DATA+
2	DATA-	4	GND

Attention!
Never plug in with force or in wrong direction.

RJ45 Port:



RJ45 Port					
Pin	Signal	Pin	Signal	Pin	Signal
1	BI_DA+	4	BI_DC+	7	BI_DD+
2	BI_DA-	5	BI_DC-	8	BI_DD-
3	BI_DB+	6	BI_DB-		