



Einhell



EXPERT

Cordless Scarifier / Aerator

GC-SC 18/28 Li-Solo

Item No.: 3420604

Ident No.: 21010

Bar Code: 4006825655223

The Einhell GC-SC 18/28 Li Solo cordless scarifier provides cordless freedom in home grounds and gardens of up to 200 m² (recommended). Batteries from the PXC series are interchangeable. A brushless electric motor drives the cordless scarifier, which has a housing made of impact-resistant plastic. As an option it is available with an aerator roller and a catch basket as a 3-in-1 combination tool. The ball-bearing cutting unit has 12 rotating blades. For the user's comfort there are 3 working depth settings, a transport position, and a long handle that can be folded down and adjusted in height. Large wheels exert less stress on the lawn. One 18 V battery is needed for operation. Delivery does not include a battery or charger.

Features & Benefits


- Member of the Power X-Change family, 1x18V batteries necessary
- Powerful brushless motor
- Ball-bearing scarifier drum with 12 rotating knives.
- Scarifying depth adjustment, 3 levels + transport position
- Foldable and height adjustable guide rail.
- Wide wheels exert less stress on the lawn
- Impact-resistant plastic housing
- Recommended for lawn areas up to 200 m² (depending on batteries)
- Supplied without battery and charger (available separately)
- Optional extensible with aerator roller and catch bag

Technical Data

- Working width	280 mm
- Number of knives	12 Pieces
- Wheel diameter front	150 mm
- Wheel diameter rear	100 mm

Logistic Data

- Tool weight	6.65 kg
- Gross Weight	8.2 kg
- Dimensions single packaging	505 x 480 x 242 mm
- Pieces per export carton	1 Pieces
- Gross weight of export carton	8.2 kg
- Dimensions export carton	518 x 490 x 245 mm
- Container quantity (20"/40"/40"HC)	396 828 920



Available as special accessories



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Areator roller GC-SC 18/28 Li
Scarifier Accessory
Item No.: 3405941
Bar Code: 4006825658804
Einhell Accessory



Scarifier rolle GC-SC 18/28 Li
Scarifier Accessory
Item No.: 3405942
Bar Code: 4006825658811
Einhell Accessory

18V 4,0Ah PXC Starter Kit 2
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 4,0Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



Catch Bag GC-SC 18/28 Li
Scarifier Accessory
Item No.: 3405940
Bar Code: 4006825658798
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 2
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory

Battery-Running-Times

One Battery for All


scarifying¹
(m²)

One Battery for All	scarifying ¹ (m ²)
1.5 Ah	60
2.0 Ah	80
2.5 Ah	100
3.0 Ah	120
4.0 Ah	160
5.2 Ah	210
6.0 Ah	240

Test setup:

1) -