

Monitor Mount with Articulating Arm and Laptop Riser



Actual product may vary from photos

User Manual SKU#: ARMUNONB

For the latest information and specifications visit
www.startech.com/ARMUNONB

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

Safety Statements

Safety Measures

- Wiring terminations should not be made with the product and/or electric lines under power.
- Cables (including power and charging cables) should be placed and routed to avoid creating electric, tripping or safety hazards.

Mesures de sécurité

- Les terminaisons de câblage ne doivent pas être effectuées lorsque le produit et/ou les câbles électriques sont sous tension.
- Les câbles (y compris les câbles d'alimentation et de chargement) doivent être placés et acheminés de façon à éviter tout risque électrique, de chute ou de sécurité

安全対策

- 電源が入っている状態の製品または電線の終端処理を行わないでください。
- ケーブル(電源ケーブルと充電ケーブルを含む)は、適切な配置と引き回しを行い、電気障害やつまづきの危険性など、安全上のリスクを回避するようにしてください。

Misure di sicurezza

- I terminali dei fili elettrici non devono essere realizzate con il prodotto e/o le linee elettriche sotto tensione.
- I cavi (inclusi i cavi di alimentazione e di ricarica) devono essere posizionati e stesi in modo da evitare pericoli di inciampo, rischi di scosse elettriche o pericoli per la sicurezza.


Säkerhetsåtgärder

- Montering av kabelavslutningar får inte göras när produkten och/eller elledningarna är strömförda.
- Kablar (inklusive elkablar och laddningskablar) ska dras och placeras på så sätt att risk för snubblingsolyckor och andra olyckor kan undvikas.

Table of Contents


Safety Statements	2
Product Diagram	4
Product Dimensions	5
Technical Specifications	6
Product Information	8
Package Contents	8
Installation Requirements	11
Assembly	11
Attaching the Clamp to a Surface	11
Attaching the Laptop Tray to the Swivel Arm	12
Attaching the Swivel Arm to the Pole and Clamp	14
Attaching the Extension Arm	16
Attach a display to the spring arm	17
Attaching the Spring Arm to the Extension Arm	19
Adjust the height tension of the spring arm	21
Adjusting the Swivel Tension of the Display Mount	22
Routing the Cables	22

Product Diagram




1	<i>Rubber Pads</i>	6	<i>Cable Management</i>
2	<i>Laptop Tray</i>	7	<i>Pole</i>
3	<i>Extension Arm</i>	8	<i>Height-Adjustment Ring</i>
4	<i>Swivel Arm</i>	9	<i>Cable-Management Clip</i>
5	<i>Monitor Mount</i>		

Product Dimensions



Technical Specifications

Type of Measurement	Measurement
<i>Display Size</i> 	<i>15 to 27 in. (381 mm to 686 mm)</i>
<i>Monitor Mount Weight Capacity</i> 	<i>Up to 17.6 lb. (8 kg)</i>
<i>Laptop Tray Weight Capacity</i> 	<i>Up to 17.6 lb. (8 kg)</i>

<i>Tilt</i> 	<i>-90° to + 85°</i>
<i>Swivel</i> 	<i>180°</i>
<i>Rotate</i> 	<i>360°</i>
<i>VESA Monitor Mount</i> 	<i>75 x 75 mm</i> <i>100 x 100 mm</i>

Product Information

Package Contents



Swivel Arm

Qty: One




Extension Arm

Qty: One



Laptop Tray

Qty: One



Spring Arm

Qty: One



Pole and Clamp

Qty: One



M4x12 Screws

Qty: Four



M4x30 Screws

Qty: Four



M5x12 Screws

Qty: Four



M6x25 Screw

Qty: One



Cable-Management Clip

Qty: One



M3 Hex Key



M5 Hex Key




M5 Nuts
Qty: Four



Height-Adjustment Ring
Qty: One



Spacers
Qty: Four




Cable-Management Clip
Qty: Two



Rubber Pads

Qty: Four



Plastic Cap

Qty: One

Installation Requirements

- Phillips Head Screwdriver
- Adjustable Wrench

Assembly

Warning: Make sure to assemble the ARMUNONB according to the following instructions. Failure to do so may result in personal injury or property damage.


If you exceed the weight capacity of the monitor mount or the laptop tray, the ARMUNONB may not work as expected and you could experience personal injury or property damage.

Never operate the ARMUNONB if parts are missing or damaged.

Attaching the Clamp to a Surface

Note: The desk clamp can be attached to a desk or table up to a thickness of 9 cm (90 mm).

1. Turn the clamping knob on the pole and clamp (5) counterclockwise until the clamp can slide over the edge of the desk or table.
2. Slide the pole and clamp all the way onto the desk or table.
3. To tighten the clamp, turn the clamping knob clockwise until the clamp is securely fastened to the desk.




Attaching the Clamp to a Surface

Attaching the Laptop Tray to the Swivel Arm


1. Insert the four M5x12 screws through the laptop tray and into the four holes in the VESA mount on the swivel arm.

2. Thread the four M5 nuts onto the M5x12 screws.



Thread the Four M5 Nuts onto the M5x12 Screws


3. Use a wrench to tighten the M5 nuts.
4. Remove the backing from the four rubber pads and affix them to the laptop tray where appropriate to prevent the laptop from slipping.



Fixing the Rubber Pads on the Laptop Tray


Attaching the Swivel Arm to the Pole and Clamp

1. Turn the adjustable collar on the height-adjustment ring counterclockwise and pull the height-adjustment ring off of the pole and clamp.




Pulling the Height-Adjustment Ring off of the Pole

2. Slide the swivel arm down the pole and clamp.



Sliding the Swivel Arm

3. Once the swivel arm is at the desired height, use the M5 hex key to turn the screw in the swivel arm clockwise to tighten it in place.




Use the M5 Hex Key to Tighten the Screw

- 4.


Attaching the Extension Arm

1. Slide the height-adjustment ring down the pole and clamp until it's at the height that you want the extension arm to sit at.
2. Turn the adjustable collar on the height-adjustment ring clockwise to tighten it in place.
3. Slide the extension arm down the pole until it's sitting on the height-adjustment ring.



Sliding the Extension Down the Pole

4. To adjust the swivel tension of the extension arm, use the M3 hex key to turn the screws in the extension arm clockwise or counterclockwise.




Adjusting the Swivel Tension

Attach a display to the spring arm

Caution! To prevent scratching, you should handle the surface of the display with care when you attach it to the spring arm.


If you exceed the weight capacity of the mount, the ARMU-NONB may not work as expected and you could experience personal injury or property damage.

1. If the VESA mount sits flush against the installation surface on the display, insert the four M4x12 screws through the VESA mount on the spring arm and into the mounting holes on the back of the display.
2. Use a Phillips screwdriver to tighten the screws.



Mounting the VESA Mount Flush Against a Monitor


3. If the VESA mount doesn't sit flush against the installation surface on the display, you need to use the provided spacers. Insert the four M4x30 screws through the VESA mount on the spring arm, into the four spacers, and into the mounting holes on the back of the display.
4. Use a Phillips screwdriver to tighten the screws.



Mounting the VESA Mount Using Spacers


Attaching the Spring Arm to the Extension Arm

1. Carefully lift the spring arm with the display attached and place it onto the extension arm.



Placing the Monitor on the Extension Arm

2. Insert the M6x25 screw through the extension arm, the spring arm, and into the plastic cap.




Attaching the Plastic Cap

3. Use a screwdriver to tighten the M6x25 screw.

Adjust the height tension of the spring arm


1. You can adjust the height tension of the spring arm to make sure that the display stays in place, regardless of the weight of the display.
2. If the display doesn't stay in place or the movement is stiff, do one of the following:
 - To increase the tension, use the M5 Allen key to turn the screw in the spring arm clockwise.
 - To decrease the tension, use the M5 Allen key to turn the screw in the spring arm counterclockwise.



Adjusting the Height Tension

Adjusting the Swivel Tension of the Display Mount

- To adjust the swivel tension of the display mount, use the M5 Allen key (12) to turn the screw on the top of the VESA mount clockwise or counterclockwise.



Adjusting the Swivel Tension


Routing the Cables

Warning: Make sure that you leave enough slack at the arm joints so that the arms can be fully extended.

Make sure that the cables that you're routing are unplugged before you complete the following steps.

1. Pull out the cable rungs on the spring arm and thread the display cable through the rungs.
2. Thread the display cable through the cavity in the underside of the extension arm.
3. Hold the display cable against the pole and clamp while you slide the cable-management clip (pole) over the cable and onto the pole.

4. Snap the cable-management clip (laptop arm) onto the swivel arm.
5. Run the laptop power cable along the swivel arm and through the hook in the cable-management clip (laptop arm).
6. To adjust the placement of cable-management clip (laptop arm) on the swivel arm, slide the cable-management clip left or right.



Routing the Cables

Warranty Information

This product is backed by a five-year warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product.

Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Hard-to-find made easy. At StarTech.com, that isn't a slogan. It's a promise.

StarTech.com is your one-stop source for every connectivity part you need. From the latest technology to legacy products — and all the parts that bridge the old and new — we can help you find the parts that connect your solutions.

We make it easy to locate the parts, and we quickly deliver them wherever they need to go. Just talk to one of our tech advisors or visit our website. You'll be connected to the products you need in no time.

Visit www.startech.com for complete information on all StarTech.com products and to access exclusive resources and time-saving tools.

StarTech.com is an ISO 9001 Registered manufacturer of connectivity and technology parts. StarTech.com was founded in 1985 and has operations in the United States, Canada, the United Kingdom and Taiwan servicing a worldwide market.

Reviews

Share your experiences using StarTech.com products, including product applications and setup, what you love about the products, and areas for improvement.

StarTech.com Ltd.

45 Artisans Cres.
London, Ontario
N5V 5E9
Canada

StarTech.com LLP

2500 Creekside Pkwy.
Lockbourne, Ohio
43137
U.S.A.

StarTech.com Ltd.

Unit B, Pinnacle
15 Gowerton Rd.,
Brackmills
Northampton
NN4 7BW
United Kingdom

FR: startech.com/fr

DE: startech.com/de

ES: startech.com/es

NL: startech.com/nl

IT: startech.com/it

JP: startech.com/jp