



USB Stereo Headset with controller




Model: Xstream P7

QuickGuide

English

www.adesso.com

DESCRIPTION



How to use Copilot in Windows?

Experience Microsoft Copilot on Windows devices using the Copilot app! Copilot helps you get answers and inspiration from across the web, supports creativity and collaboration, and helps you focus on the task at hand.


Get started with Copilot

To get started, open the Copilot app from the Start menu or use the Copilot icon if present on your Windows taskbar. If your device keyboard/mouse/headphone includes a dedicated Copilot key, you can also use it to launch Copilot. Copilot uses your Microsoft account to provide personalized assistance and access to a wide range of features.



Interact with Copilot

Copilot is designed to deliver AI-powered assistance in a convenient manner, enabling you to seamlessly engage with generative AI on Windows.



LIMITED WARRANTY

Adesso provides a one year limited warranty for all of its products against defects in material and workmanship.

During this period, Adesso will repair or replace any product which proves to be defective. However, Adesso will not warranty any product which has been subject to improper freight handling, shipping abuse, neglect, improper installation or unauthorized repair. The warranty will not cover products installed with components not approved by Adesso and products where the sealed assembly trace has been broken.

If you discover a defect, Adesso will, at its option, repair or replace the product at no charge to you provided you return it during the warranty period with freight charges pre-paid to Adesso. Before returning any product, you must obtain a Return Merchandise Authorization number (RMA). This RMA # must be clearly marked on the outside of the package you are returning for warranty service. Be certain to also include your name, shipping address (no PO Boxes), telephone number, and a copy of the invoice showing proof of purchase in the package.


FAQs: <https://www.adesso.com/faqs/>

Email Support: support@adesso.com

Telephone Support: (800) 795-6788

9:00AM to 5:00PM PST MONDAY - FRIDAY

CONTENTS




GETTING STARTED

CONNECTING THE HEADSET

Connect via USB-C

1. Plug the USB-C connector into your computer USB-C port.




Connect via USB-A

1. Plug the USB-C connector into the USB-A adapter.

2. Plug the USB-A connector into your computer USB-A port.

Note: Only use the USB-A adapter with the provided headset.



INTRODUCTION

Xstream P7 stereo headphones offer an exceptional audio experience. They come with convenient button controls for easy operation. The buttons support Copilot functionality, enabling seamless interaction. The voice dictation feature allows for effortless communication. You can also mute the microphone as needed. Enjoy high-quality sound and smart control with these headphones.

Features:

- Connection: USB-C or USB-A
- Inline Controller: Copilot, Voice Dictation, Enter, Microphone Mute
- Unit Driver: 40mm
- Frequency: 20Hz-20KHz
- Sensitivity: 110dB $\pm$ 3dB
- Impedance: 32 ohm
- Built-in Mic: Unidirectional
- Dimension: 155*55*170MM
- Net Weight: 0.3 lbs (140g)
- Cord Length: 6.23 ft (1.9m)

REQUIREMENTS:

Operating System:


- Operating System: Windows® 11/10/8 / 7, Mac Os® and above Android, Chrome
- Voice Dictation: Only systems above Windows® 10 are supported.
- Copilot: Only systems above Windows® 11 are supported.

Connectivity Interface:

- Available USB-C
- USB C to USB A adapter


HEADSET FIT

Adjust headset by sliding headband open or closed on both sides.



ADJUSTING THE MICROPHONE BOOM


1. Microphone boom rotates 130 degrees. Wear it on left side. For the best music experience, we recommend wearing the headset with the microphone on the left. Left/Right indicators can be found on the side of the headset.
2. Adjust flexible microphone boom location to capture voice better.



How to use Windows Voice Dictation?

Use dictation to convert spoken words into text anywhere on your PC with Windows 10. Dictation uses speech recognition, which is built into Windows 10, so there's nothing you need to download and install to use it.

To start dictating, select a text field and press the  to open the dictation toolbar. Then say whatever's on your mind. To stop dictating at any time while you're dictating, say "Stop dictation."



If you're using a tablet or a touchscreen, tap the microphone button on the touch keyboard to start dictating. Tap it again to stop dictation, or say "Stop dictation."